


PRESTO®

8-Quart Stainless Steel Pressure Cooker




Visit us on the web at www.GoPresto.com

©2007 by National Presto Industries, Inc.

Instructions and Recipes

TABLE OF CONTENTS

Important Safeguards	2
Introduction	2
Getting Acquainted	3
How to Use	4
Important Safety Information	5
Care and Maintenance	6
Helpful Hints	7
Questions and Answers	8
Soups and Stocks	10
Seafood	13
Poultry	17
Meats	21
Vegetables	26
Dry Beans and Peas	29
Grains	31
Desserts	34
Recipe Index	37
Service and Parts Information	38
Warranty	38

This is a  Listed appliance. The following Important Safeguards are recommended by most portable appliance manufacturers.

IMPORTANT SAFEGUARDS

To reduce the risk of personal injury or property damage, basic safety precautions should always be followed, including the following:

1. Read all instructions. Improper use may result in bodily injury or property damage.
2. Always check the vent pipe before use. Hold cover up to light and look through vent pipe to be certain it is clear.
3. Always check the air vent/cover lock to be sure it moves freely before use.
4. Do not fill pressure cooker over $\frac{2}{3}$ full. For soup, rice, and dried vegetables which expand during cooking, do not fill cooker over $\frac{1}{2}$ full. Overfilling may cause a risk of clogging the vent pipe and developing excess pressure. See food preparation instructions.
5. Do not pressure cook applesauce, cranberries, rhubarb, pearl barley, cereals, pastas, grains, dried soup mixes, or any dry beans and peas which are not listed on the chart on page 29. These foods tend to foam, froth, and sputter and may block the vent pipe and air vent/cover lock.
6. This appliance cooks under pressure. Improper use may result in scalding injury. Make certain pressure cooker is properly closed before operating; cover handles must be directly above the body handles. See “How To Use” instructions.
7. Do not place the pressure cooker or attempt to pressure cook in a heated oven.
8. Extreme caution must be used when moving a pressure cooker containing hot liquids. Do not touch hot surfaces. Use handles or knobs.
9. Do not open cooker until internal pressure has been completely reduced, air vent/cover lock has dropped, and no steam escapes when the pressure regulator is removed. See “How To Use” instructions.
10. **Caution:** To ensure safe operation and satisfactory performance, replace the overpressure plug every time you replace the sealing ring or sooner if it becomes hard, deformed, cracked, worn or pitted. It is recommended that the sealing ring and overpressure plug be replaced at least every two years.
11. Close supervision is necessary when the pressure cooker is used near children. It is not recommended that children use the pressure cooker.
12. When normal operating pressure is reached you will hear and/or see a steady flow of steam releasing from the pressure regulator. Lower the heat as necessary to maintain a very slow, steady flow of steam from the pressure regulator. If the heat is not lowered, excess steam will escape, liquid will be evaporated and food may scorch.
13. **Caution:** Do not use pressure cooker on an outdoor LP gas burner or gas range over 12,000 BTU’s.
14. Do not use this pressure cooker for other than intended use.
15. Do not use this pressure cooker for pressure frying with oil.

SAVE THESE INSTRUCTIONS

THIS PRODUCT IS FOR HOUSEHOLD USE ONLY.

INTRODUCTION

Welcome to the world of pressure cooking. With your new Presto® Pressure Cooker, you’ll discover how fast and easy it is to prepare a wide variety of delicious foods—especially foods that emphasize good health and nutrition along with good taste.

The pressure cooker is perfect for the way we live and eat today. It’s ideal for preparing many of the lighter foods that help keep us healthy and fit. It preserves flavors and nutrients, tenderizes leaner cuts of meat, and, best of all, it cooks foods three to ten times faster than ordinary cooking methods. And, it’s even possible to cook several foods in the pressure cooker at the same time without the flavors intermingling.


We have included some traditional family favorites that are especially well suited to the many advantages of pressure cooking. For your convenience, we have also provided nutritional information for all of the recipes in this book.

To help get started with your new pressure cooker, be sure to read the “GETTING ACQUAINTED” section beginning on the next page.

GETTING ACQUAINTED


Your pressure cooker is like a saucepan with a very special cover that locks in place. Air is automatically exhausted and steam is sealed inside creating pressure within the unit. Under pressure, internal temperatures in the cooker are raised above the normal boiling point of water, causing foods to cook faster. At 15 pounds pressure, a temperature of 250° F. (or 121° C.) is reached inside the pressure cooker. This higher temperature speeds cooking and the moist steam atmosphere tenderizes meats naturally.

It is important to become familiar with the various parts and features of the pressure cooker (Fig. A) and to read the "HOW TO USE" section beginning on page 4 before using the unit for the first time.



Before the first use, remove the sealing ring (Fig. B) by simply pulling it out of the inside rim of the cover.

Wash sealing ring, cover, body, trivet, and steamer basket (Fig. A) in hot, sudsy water to remove any packaging material and white manufacturing lubricant. Rinse all parts with warm water and dry. Then, replace the sealing ring, being careful to fit it under the stop tabs and the lock pin (Fig. B) which are located on the inside rim of the cover.



HOW TO USE

To assure the very best results every time, carefully follow these step-by-step instructions for pressure cooking. You may find it helpful to refer back to Fig. A on page 3.

1. Prepare ingredients according to the directions in the pressure cooking recipe you have selected. If a larger quantity is desired, you may double ingredients. Be sure not to overfill the pressure cooker (see page 5).

Pour liquid into the cooker body, as specified in the recipe or timetable. This liquid is usually water. However, some recipes will call for other liquids, such as wine.

2. Place the trivet and steamer basket into the cooker, if called for in the recipe (see Helpful Hints on page 7 for guidance on when to use). If using the trivet, position it in the cooker so the loop ends are towards the bottom of the cooker (Fig. C).
3. **IMPORTANT:** Look through the vent pipe to make certain that it is clear before closing the cover (Fig. D). See safety information on page 5.

Place the cover over the body (Fig. E), aligning the ▼ mark on the cover with the arrow on either of the body handles. Move the cover handle slightly until the cover drops into position.

4. Close the cover securely by rotating it clockwise until the cover handles are directly above the body handles. **The pressure cooker is completely closed when the cover handles are directly above the body handles (Fig. F).** Do not try to rotate it beyond this point.
5. Place the pressure regulator on the vent pipe and rotate clockwise until the lever on the regulator is aligned with the pressure arrow (Fig. G).
Note: It may be necessary to apply slight pressure when positioning the regulator on the vent pipe to seat it properly.

6. Using a high heat setting, heat the pressure cooker. As pressure is building, a small amount of steam will be released from the pressure regulator. You will know your cooker has reached 15 pounds pressure when you hear and/or see a steady flow of steam releasing from the pressure regulator.







NOTE: The air vent/cover lock may move up and down a few times when cooking first begins as it automatically exhausts air from the pressure cooker. Steam will be noticeable. This is normal. When pressure begins to build, it slides up, locking the cover on. Once the cooker has sealed, the air vent/cover lock will remain in the up position until pressure is released (Fig. H).

7. Cooking time begins when you hear and/or see a steady flow of steam releasing from the pressure regulator. Lower the heat as necessary to maintain a very slow, steady flow of steam and cook for the length of time indicated in the recipe or cooking chart. If excess steam is allowed to escape, too much liquid will evaporate and food may scorch. Never leave your pressure cooker unattended at high heat settings. It could boil dry, overheat, and cause damage to the pressure cooker.

8. When cooking time is complete, turn off burner. If using an electric stove, remove pressure cooker from burner.

9. Reduce pressure according to the recipe or timetable instructions. If the instructions say "Let the pressure drop of its own accord," set the pressure cooker aside to cool until pressure is completely reduced. If the instructions state, "Cool cooker at once," you can release pressure safely using either of the following quick cool methods:

A) Turn the pressure regulator/steam release valve




counter-clockwise until the lever on the regulator is aligned with the steam release arrow (Fig. I). Steam will be rapidly released.

Caution: Misuse of the cooker (such as overfilling, failing to follow procedures for soaking dry beans and peas, failure to use a covered bowl when preparing rice, or quick cooling when the recipe calls for letting the pressure drop of its own accord) can result in liquid and/or food particles being simultaneously released with the steam.

If this occurs, turn the pressure regulator/steam release valve clockwise until the lever on the regulator is aligned with the pressure arrow. Steam, liquid, and food will no longer be released. Finish reducing pressure quickly by cooling the pressure cooker under a running water faucet or pour cold water over it until pressure is completely reduced. Pressure is completely reduced when the air vent/cover lock has dropped.

After removing cover, look through the vent pipe to make sure it is clear. If it is blocked or partially blocked, clean it with a small brush or pipe cleaner (see page 6).



- B) Cool the pressure cooker under a running water faucet or pour cold water over it until pressure is completely reduced. Pressure is completely reduced when the air vent/cover lock has dropped. **Note: Do not set hot cooker in a molded sink as it could damage the sink.**

If the air vent/cover lock remains in its raised position, there is still pressure inside the pressure cooker. Continue to cool until the air vent/cover lock drops.

10. After pressure has been completely reduced, remove the cover. To open the cover, turn it counterclockwise until the ▼ on the cover aligns with the arrow on either of the body handles. Then, lift the cover toward you to keep any steam away from you. If the cover turns hard, there still may be some pressure in the unit. **Do not force the cover off.** Continue to cool the pressure cooker until the air vent/cover lock has dropped and the cover turns easily.
11. If you have used the steamer basket, use potholders to grab the two handles on the sides of the steamer basket and carefully lift the basket out of the cooker. Food is ready to serve.
12. Your pressure cooker is now ready to clean. Remove pressure regulator and sealing ring and clean as described in the Care and Maintenance section found on pages 6 and 7.

IMPORTANT SAFETY INFORMATION


Cooking under pressure enables you to prepare food both quickly and deliciously. If used properly, your pressure cooker is one of the safest appliances in your kitchen. To ensure safe operation, make sure you always observe the following simple rules whenever you use the pressure cooker:

1. **Never overfill the pressure cooker.** — The pressure regulator is designed to maintain cooking pressures at a safe level. It relieves excess pressure through the vent pipe as a very, slow steady flow of steam escapes. Many foods tend to expand when cooked. If the cooker is overfilled, expansion of food may cause the vent pipe to become blocked or clogged. If the vent pipe becomes blocked, it cannot relieve excess pressure.

There are a few foods such as rice, grains, dry beans and peas, and soups which expand so much or foam and froth while cooking that the cooker should never be filled above the $\frac{1}{2}$ fill line. For other foods, never fill the cooker above the $\frac{2}{3}$ fill line.

For your convenience, both the $\frac{2}{3}$ and $\frac{1}{2}$ full levels are marked by indentations on the side of the pressure cooker body (see Fig. J). The upper marking indicates the $\frac{2}{3}$ full level and the lower the $\frac{1}{2}$ full level. In addition, in each section of the recipes you will find instructions on the maximum fill level for each type of food.

Reminder: When cooking any food, do not let any portion extend above the maximum fill mark. When cooking rice, grains, dry beans and peas, and soups, the cooker should never be more than $\frac{1}{2}$ full.



2. **Always add cooking liquid.** — If an empty pressure cooker is left on a hot burner or if a cooker boils dry and is left on a heated burner, the cooker will overheat excessively causing possible discoloration and/or damage to the cooker.

3. **Always look through the vent pipe before using the cooker to make sure it is clear.** — If the vent pipe is blocked, it cannot function as it should and thus cannot relieve excess pressure. Pressure may then build to unsafe levels. To clean the vent pipe, see the “Care and Maintenance” section below.
4. **Always fully close the pressure cooker.** — The cooker is fully closed when the cover handles are directly above the body handles. Your pressure cooker has specially designed lugs on the cover and body which lock the cover in place when the cooker is fully closed. However, if the cooker is not fully closed, the lugs cannot lock the cover onto the body. It’s possible that pressure could build inside the cooker and cause the cover to come off and result in bodily injury or property damage. Always be sure the cover handles are directly above the body handles (see page 4, Fig. F). Do not turn past handle alignment.
5. **Never open the cooker when it contains pressure.** — The air vent/cover lock provides a visual indication of pressure inside the cooker. When it is up, there is pressure. When it is down, there is no pressure in the cooker and it can be opened. If the pressure cooker is opened before all of the pressure is released, the contents of the cooker will erupt and could cause bodily injury or property damage.
6. **Replace the overpressure plug if it is hard, deformed, cracked, worn or pitted.** — The overpressure plug is a secondary pressure relief valve which is designed to relieve excess pressure by releasing from the cooker cover in the event that the vent pipe becomes blocked. The overpressure plug is made of rubber, and when new, is soft and pliable. Over time, depending on the frequency and type of use, rubber becomes hard and inflexible. When hard and inflexible, the overpressure plug loses its ability to act as a secondary pressure relief valve. It should be replaced immediately.

Should the overpressure plug ever be forced out of the cover due to excess pressure while cooking, it is important to call the Test Kitchen at 1-800-368-2194. **Do not attempt to use the released overpressure plug.**
7. **Always follow special procedures found in the instruction book when pressure cooking rice, grains, and dry beans and peas.** — During cooking, dry beans and peas tend to froth and foam which could cause the vent pipe to become blocked. Therefore, dry beans and peas need to be soaked and cooked according to instructions beginning on page 29. Using this method will keep foam at safe levels during cooking. Like dry beans and peas, rice and grains tend to froth and foam during cooking; therefore, to contain foaming and frothing during the cooking period, rice and grains must be prepared in a bowl in the pressure cooker according to directions on page 31.
8. **Never pressure cook applesauce, cranberries, rhubarb, cereals, pastas, dried soup mixes, or dry beans and peas which are not listed in the chart on page 29.** — These foods expand so much as a result of foaming and frothing that they should never be cooked under pressure.

CARE AND MAINTENANCE

1. All parts of your pressure cooker, including the sealing ring and pressure regulator, are fully immersible for easy cleaning. When washing the unit, however, the sealing ring should always be removed to allow easy cleaning of the inside rim of the cover. The sealing ring should be washed with hot, sudsy water after each use.
2. To be sure the vent pipe is clear, hold the cover up to the light and look through the vent pipe. Clean it with a small brush or pipe cleaner if it is blocked or partially blocked (Fig. K). Also clean the vent pipe nut as shown.
3. Occasionally remove the air vent/cover lock in the pressure cooker cover handle for cleaning. To remove the air vent/cover lock, place your finger over the hole in the cover handle and remove the rubber gasket from the air vent/cover lock on the underside of the cover (Fig. L). Push the air vent/cover lock through the top of the cover and wash it and the gasket in hot sudsy water. The metal shaft of the air vent/cover lock may be cleaned with a nylon mesh pad. Clean the hole in the cover handle with a small brush. After cleaning, reinsert the metal shaft of the air vent/cover lock from the top side of the cover down through the cover handle hole (Fig. M). Place a finger over the handle hole (to keep the cover lock from falling out) and turn the cover over. Wet the rubber gasket and push onto the end of the metal shaft until it snaps into the groove on the shaft. The gasket should fit loosely in the groove.






Fig. K



4. The overpressure plug can also be removed for cleaning by pushing it out of its opening from the top of the cover handle. After cleaning, reinsert it by pushing the domed side of the plug into the opening from the underside of the cover, until the bottom edge is fully and evenly seated against the underside of the cover (Fig. N). When the overpressure plug is properly installed, the word (TOP) will be visible on the overpressure plug when viewing the outside of the cover.



5. To bring out its luster, the outside surface of your pressure cooker can be cleaned occasionally with a silver polish or any other fine, non-abrasive polish. If food residue adheres to the pressure cooker body, clean with a vegetable brush, a nylon pad, or a non-abrasive powder cleanser, such as Bon ami* polishing cleanser or Cameo* copper, brass & porcelain cleaner. Do not use steel wool or cleaners with chlorine bleach.

Take care not to overheat your stainless steel pressure cooker. Very high heat can sometimes cause vari-colored stains, called heat tints, in stainless steel. Heat tints can usually be removed by using a non-abrasive powder cleanser.

6. When not in use, store your pressure cooker in a dry place with the cover inverted on the body. If the cover is locked on, unpleasant odors may form inside the unit and the sealing ring could be damaged.
7. As is the case of all cookware, avoid chopping or cutting food inside the cooker with a knife or other sharp utensil.
8. If the body or cover handles become loose, tighten them with a screwdriver.
9. The sealing ring, overpressure plug, and rubber gasket of the air vent/cover lock may shrink, become hard, deformed, cracked, worn, or pitted with normal use. Exposure to high heat, such as a warm burner or oven top, will cause these parts to deteriorate rapidly. When this happens, replace the sealing ring, overpressure plug, and small rubber gasket of the air vent/cover lock. Replace the sealing ring and overpressure plug at least every two years.

Leakage between the cover and body is usually caused by shrinkage of the sealing ring after prolonged use. Replace the sealing ring. Whenever you replace the sealing ring, replace the overpressure plug also.

10. The formation of a small amount of moisture under the pressure regulator is normal when cooking first begins. It is the result of the temperature of the regulator being lower than the rest of the unit.

A small amount of steam or moisture may also be visible around the overpressure plug and air vent/cover lock as cooking begins. It should stop when pressure begins to build and the overpressure plug and air vent/cover lock seal. If leakage continues, clean or replace the overpressure plug and/or air vent/cover lock assembly. The pressure cooker will not seal if the gasket for the air vent/cover lock is cracked.

Do not operate your pressure cooker with continual leakage. If the preceding steps do not correct the problem, return the entire unit to the Presto Factory Service Department (see page 38).

11. If the pressure cooker becomes difficult to open or close, the sealing ring should be replaced. If for any reason the pressure cooker cannot be opened, contact the Consumer Service Department in Eau Claire, WI at 1-800-877-0441.

Any maintenance required for this product, other than normal household care and cleaning, should be performed by the Presto Factory Service Department (see page 38).

HELPFUL HINTS

- ◆ Your favorite recipes may be adjusted for cooking in the pressure cooker by following the general directions in this book for the particular type of food being cooked. Decrease the cooking time for your recipe by $\frac{2}{3}$ since pressure cooking is much faster than ordinary cooking methods. For example, if your ordinary cooking method requires 45 minutes, in the pressure cooker the cooking time will be 15 minutes. Because there is very little evaporation, the amount of liquid used should be decreased. Use about 1 cup more liquid than you'll desire in your finished dish. But, remember, there must always be water or some other liquid in the pressure cooker to produce the necessary steam.
- ◆ Use the trivet and steamer basket when it is desirable to cook foods out of the cooking liquid. When foods are pressure cooked out of the liquid, flavors will not intermingle. Therefore, it is possible to cook several foods at once, as long as they have similar cooking times. If it is desirable to blend flavors, do not use the trivet and steamer basket.

*Bon ami polishing cleanser is a registered trademark of Faultless Starch/Bon Ami Co. Cameo copper, brass & porcelain cleaner is a registered trademark of Church & Dwight Co., Inc.

- ◆ Many different cooking liquids can be used in a pressure cooker. Wine, beer, bouillon, fruit juices, and of course water all make excellent cooking liquids in the pressure cooker.
- ◆ Beautiful desserts and side dishes can be prepared in the pressure cooker using individual or small metal molds or glass custard cups, which are ovenproof. Fill molds $\frac{2}{3}$ full to allow for expansion of food, and fit them loosely into the pressure cooker in the steamer basket. Do not fill the pressure cooker over $\frac{2}{3}$ full.
- ◆ If a recipe says to cook 0 minutes, release pressure immediately after pressure cooker reaches cooking pressure.
- ◆ Release pressure quickly after cooking delicate foods such as custards and fresh vegetables. For other foods, like meats, soups, and grains, let the pressure drop of its own accord.
- ◆ When pressure cooking at high altitudes, the cooking time needs to be increased 5% for every 1000 feet above the first 2000 feet. Following this rule, the times should be increased as follows:

3000 ft.	5%	5000 ft.	15%	7000 ft.	25%
4000 ft.	10%	6000 ft.	20%	8000 ft.	30%

Because pressure cooking times are increased at altitudes above 2000 feet, an additional $\frac{1}{2}$ cup cooking liquid will be needed.

- ◆ If you have any questions on recipes, time charts, or the operation of your pressure cooker, call or write: Test Kitchen, National Presto Industries, Inc., 3925 North Hastings Way, Eau Claire, Wisconsin 54703-3703, phone 1-800-368-2194. You may also contact us at our website www.GoPresto.com. When writing, please include a phone number and a time when you can be reached during weekdays, if possible. Written inquiries will be answered promptly by letter or telephone.

QUESTIONS AND ANSWERS


Occasionally the cover is hard to open or close. What causes this? What should I do?

In order for pressure to build inside your pressure cooker, the unit has a special cover which provides an airtight fit. Because of this, you may find that on occasion the cover may be difficult to open or close. The following suggestions will help if this happens:

If the cover seems hard to close, be sure you have aligned the ▼ mark on the cover with the arrow on either of the body handles. Move the cover until it drops into position. Then, press down firmly on the cover handles and rotate the cover clockwise until the cover handles are directly above the body handles.

If, after browning meat or poultry, the cover is difficult to close, it may be due to expansion of the pressure cooker body from heating. Remove the cover and allow the pressure cooker body to cool slightly and try again. Do not place the pressure cooker back on the burner until it is fully closed.

If necessary, to help make the cover easier to open and close, a very light coating of cooking oil may be applied to the **underside** of the lugs on the pressure cooker body (Fig. O) and/or on the sealing ring. Use a pastry brush, a piece of cloth, or your fingertips and be sure to wipe off any excess oil.



What can be done if the food prepared in the pressure cooker has more liquid than desired?

Simmer to evaporate the excess liquid. Next time you prepare the same recipe, you may want to use a tablespoon or two less liquid.

How does one prevent overcooking?

Remember to begin timing as soon as you hear and/or see a steady flow of steam escaping from the pressure regulator. Reduce heat to maintain a very slow, steady flow of steam. It is very important to accurately time the cooking period. A Presto® kitchen timer is very helpful for this purpose. Also be sure to follow the recipe instructions for cooling the pressure cooker.

What if the food is not completely done after the recommended cooking time?

Simply bring the cooker back up to pressure and cook the food a minute or two longer.

How do I know my pressure cooker is operating properly?

When a steady flow of steam escapes from the pressure regulator, you will know your cooker is functioning correctly.

When cooking first begins, is it normal for steam to escape and moisture to form on the cover and between the handles?

It is normal for steam to escape and a slight amount of moisture leakage to form on the cover and between the handles when cooking first begins. If leakage continues, the cover handles may not be fully aligned with the body handles and, therefore, the cover lock cannot engage.

Is it normal for the air vent/cover lock to rise up partially and drop back down when cooking first begins?

It is possible that the air vent/cover lock will move up and down slightly when cooking first begins. Do not be concerned. The air vent/cover lock will remain in the up position once the cooker has sealed. However, if the air vent/cover lock continues to move up and down or rises partially, tap it lightly with the tip of a knife. If it does not rise once you have tapped it, the following may be occurring:

1. The burner is not hot enough.
2. The cooker is not fully closed (see page 4).
3. There is insufficient liquid to form steam.
4. The gasket for the air vent/cover lock needs to be replaced (see page 7).

SOUPS AND STOCKS

The pressure cooker is perfect for preparing delicious, nourishing soups and stocks in minutes instead of the hours taken by ordinary methods.

Stocks form the base for most great soups and sauces and you can even substitute a stock for water in many recipes to add extra flavor. Traditionally, stocks are made by simmering bones and scraps for hours to extract all their flavor. With the pressure cooker, you can do the same thing in just minutes by following the simple directions on the following pages.

We've also included a few favorite soup recipes and, if you have a favorite recipe of your own, try it in the pressure cooker using one of the recipes in this book as your guide. If adding dried vegetables, they must first be soaked according to directions on page 29. **Do not pressure cook soups containing barley, rice, pasta, grains, dry beans and peas which are not listed in the chart on page 29, and dried soup mixes** because they have a tendency to foam, froth, and sputter and could clog the vent pipe.

Cooked barley, rice, grains, pasta, dry beans and peas which are not listed in the chart on page 29, and dried soup mixes should be added to the soup after pressure cooking.

*FOR SOUPS AND STOCKS,
DO NOT FILL PRESSURE COOKER OVER ½ FULL!
OPERATING THE COOKER WITHOUT COOKING LIQUID OR
ALLOWING THE COOKER TO BOIL DRY WILL DAMAGE THE COOKER.*

CHICKEN SOUP

1½ pounds chicken, cut into serving pieces	½ cup chopped onion
4 cups water	¼ cup chopped celery
½ cup sliced carrots	1 teaspoon salt
	¼ teaspoon black pepper

Place all ingredients in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 12 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Remove pieces of chicken from cooker and let cool. Remove meat from bones and return meat to cooker. Heat through.

Nutrition Information Per Serving 4 servings
160 Calories, 8 g Fat, 54 mg Cholesterol

Delicious Soups From Chicken Soup...

CHICKEN SOUP STOCK — Strain Chicken Soup to make stock.

CHICKEN NOODLE SOUP — Bring soup to a boil. Add fine noodles and simmer, uncovered, 10 to 15 minutes. Salt and pepper to taste.

4 servings

CHICKEN DUMPLING SOUP — Mix together 1 beaten egg, ½ cup milk, and ½ teaspoon salt. Stir in 1½ cups flour. Drop mixture from teaspoon into bubbling Chicken Soup in cooker. Simmer dumplings uncovered 6 minutes.

4 servings

CHICKEN RICE SOUP — Add 1 cup cooked rice to Chicken Soup. Heat through. Salt and pepper to taste.

4 servings

BROWN BEEF SOUP

1½ pounds lean beef, cut into 1 inch cubes	¼ cup chopped celery
4 cups water	1 bay leaf
½ cup chopped onion	1 teaspoon parsley flakes
½ cup sliced carrots	1 teaspoon salt
	¼ teaspoon black pepper

Place all ingredients in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 12 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.**

Nutrition Information Per Serving

4 servings

295 Calories, 15 g Fat, 110 mg Cholesterol

Delicious Soups From Brown Beef Soup...

BROWN BEEF SOUP STOCK — Strain Brown Beef Soup to make stock.

ONION SOUP — Pour 2 tablespoons vegetable oil into cooker and sauté 1½ cups thinly sliced onions. Stir onions into 6 cups Brown Beef Soup Stock in cooker. Season with ¼ teaspoon pepper. Close cover securely. Place pressure regulator on vent pipe and **cook 2 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Ladle into soup bowls. Top with Parmesan cheese. If desired, garnish with croutons or toasted French bread.

6 servings

BEEF TOMATO SOUP — Add 2 cups tomato juice and 1 cup cooked rice to Brown Beef Soup. Heat through.

8 servings

BLACK BEAN SOUP

2 cups dried black beans	4 cups chicken stock or broth
1 tablespoon olive or vegetable oil	2 cups sliced carrots, ¾-inch thick
1 cup chopped onion	1 tablespoon packed brown sugar
3 cloves garlic, minced	2 teaspoons white wine vinegar
1-2 jalapeño chiles, seeded, deveined, minced	••••••
1 tablespoon chili powder	1 cup loosely packed fresh cilantro, chopped
1½ teaspoons oregano	Salt to taste
½ teaspoon allspice	

Soak beans according to instructions on page 29. Pour oil in pressure cooker. Sauté onion, garlic, chiles, chili powder, oregano, and allspice for 2 minutes. Stir in beans, chicken stock, carrots, brown sugar, and vinegar. Close cover securely. Place pressure regulator on vent pipe and **cook 12 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Remove 1 cup of bean mixture, place in blender and purée until smooth. Return to pressure cooker and stir in fresh cilantro.

Nutrition Information Per Serving

8 servings

231 Calories, 3 g Fat, 0 mg Cholesterol

SAFFRON FISH STEW

1 can (14½ ounces) chicken broth	Pinch of saffron threads
¼ cup dry white wine	or ¼ teaspoon turmeric
4 new red potatoes, quartered	••••••••
3 carrots, cut into ½-inch chunks	1 pound firm fish (halibut, haddock,
1 medium onion, finely chopped	cod, pollack) fresh or thawed,
2 cloves garlic, minced	cut into 8 pieces
¼ cup chopped parsley	1 small red pepper, cut into chunks
1 bay leaf	1 cup frozen peas, thawed

Place broth, wine, potatoes, carrots, onion, garlic, parsley, bay leaf, and saffron in pressure cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 2 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Add fish, pepper, and peas. Close cover securely. Place pressure regulator on vent pipe and **cook 1 minute with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Discard bay leaf.

Nutrition Information Per Serving

8 servings

174 Calories, 1 g Fat, 40 mg Cholesterol

MINESTRONE

1 pounds lean beef, cut into	1½ teaspoons basil
1-inch cubes	1 teaspoon salt
5 cups water	1 bay leaf
1 can (14-15 ounces) diced	¼ teaspoon black pepper
tomatoes	••••••••
½ cup chopped onion	1 can (16 ounces) Great
1 cup sliced carrots	Northern beans
¼ cup chopped celery	1 can (15 ounces) cut green
1 clove garlic, minced	beans, drained
2 tablespoons parsley flakes	2 ounces fine noodles

Place beef, water, tomatoes, onions, carrots, celery, garlic, parsley, basil, salt, bay leaf, and pepper in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 10 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Add Great Northern beans, green beans, and noodles. Simmer uncovered 10 minutes. Garnish with Parmesan cheese, if desired.

Nutrition Information Per Serving

10 servings

234 Calories, 6 g Fat, 44 mg Cholesterol

POTATO SOUP

1 tablespoon vegetable oil	¼ teaspoon basil
1 cup finely chopped onions	••••••••
½ cup finely sliced celery	1 can (12 ounces) evaporated
3 cups chicken broth	skim milk
4 cups peeled, diced potatoes	Salt to taste
¼ teaspoon white pepper	

Heat oil in pressure cooker over medium heat. Sauté onion and celery until soft. Add broth, potatoes, pepper, and basil to pressure cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 5 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Remove 2 cups of potato mixture; place in blender or food processor and process until smooth. Return to pressure cooker and stir in evaporated milk.

Nutrition Information Per Serving

6 servings

160 Calories, 2 g Fat, 2 mg Cholesterol

ZESTY HOMEMADE CHILI

- | | |
|---------------------------------|---|
| 1½ pounds ground beef | 1 tablespoon salt |
| 1 can (8 ounces) tomato sauce | 1 teaspoon ground cumin |
| ½ cup water | ½ teaspoon black pepper |
| 1 cup chopped onion | ½ teaspoon oregano |
| ¾ cup chopped green pepper | ¼ teaspoon cayenne pepper |
| 2 cloves garlic, finely chopped | •••••• |
| 1 tablespoon chili powder | 1 can (15 ounces) kidney beans,
drained and rinsed |
| ½ teaspoon black pepper | |

Turn heat selector to medium and brown meat. Add remaining ingredients except kidney beans. Close cover securely. Place pressure regulator on vent pipe and **cook 5 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Stir in kidney beans and heat through.

Nutrition Information Per Serving

432 Calories, 17 g Fat, 111 mg Cholesterol

4 servings

SEAFOOD

Seafood is the basis of some of the healthiest and most nutritious meals you can make. It is an excellent source of protein, a good source of minerals, and some vitamins, and it's low in fat and sodium.

Steaming in the pressure cooker brings out the finest, fullest flavors of seafood. The cooking time required is directly related to the thickness of the seafood. To be safe, if the fish you are cooking seems thin for its weight or if it weighs less than the recipe specifies, reduce the cooking time. Overcooking tends to toughen seafood.

*FOR FISH AND SEAFOOD,
DO NOT FILL PRESSURE COOKER OVER ⅔ FULL!
OPERATING THE COOKER WITHOUT COOKING LIQUID OR
ALLOWING THE COOKER TO BOIL DRY WILL DAMAGE THE COOKER.*

SALMON STEAKS MOUTARDE

- | | |
|--|---------------------------------------|
| 4 small salmon steaks, 1-inch thick | 1 clove garlic, minced |
| 4 tablespoons Dijon-style mustard | 1 cup dry white wine or chicken broth |
| 3-4 sprigs fresh thyme or ½ teaspoon dried thyme | 1 bay leaf |
| 1 tablespoon olive or vegetable oil | •••••• |
| 1 small onion, chopped | 2 tablespoons Dijon-style mustard |
| | 1 tablespoon constarch |

Spread each steak with 1 tablespoon mustard. Press 1 thyme sprig into mustard on each steak or sprinkle with dried thyme. Pour oil into cooker. Turn heat selector to medium and sauté onion and garlic until tender. Stir in wine and bay leaf. Position trivet in cooker. Place steaks in steamer basket on trivet. Close cover securely. Place pressure regulator on vent pipe and **cook 2 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Carefully remove steaks and rack. Keep steaks warm. Discard bay leaf. Mix 2 tablespoons mustard with cornstarch. Stir into liquid in pressure cooker. Heat until sauce boils and thickens, stirring constantly. Serve sauce with salmon steaks.

Nutrition Information Per Serving

218 Calories, 9 g Fat, 20 mg Cholesterol

4 servings

VARIATION: Substitute halibut for salmon steaks.

“SCAMPI-STYLE” SHRIMP

- | | |
|---|-------------------------------------|
| 1 pound medium raw shrimp,
peeled and deveined | ¼ teaspoon salt |
| 3 tablespoons margarine | 1 cup water |
| 2 tablespoons minced green onion | •••••• |
| 6 cloves garlic, minced | 2 tablespoons minced parsley |
| 2 teaspoons lemon juice | ¼ teaspoon grated lemon peel |

Pat shrimp dry with paper towels. Place margarine in cooker. Turn heat selector to medium and melt margarine. Sauté onion and garlic. Stir in lemon juice and salt. Cook until bubbly. Pour into metal bowl which will fit loosely in cooker. Stir in shrimp. Cover bowl firmly with aluminum foil. Pour water into cooker. Place bowl in steamer basket in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 3 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Stir in parsley and lemon peel.

Nutrition Information Per Serving

205 Calories, 11 g Fat, 173 mg Cholesterol

4 servings

SHRIMP JAMBALAYA

- | | |
|---|--|
| 1 cup long grain white rice | 2 cloves garlic, minced |
| 1½ cups water | 1 bay leaf |
| 1 cups water | 1 teaspoon basil |
| •••••• | ½ teaspoon thyme |
| 1 can (14-15 ounces) stewed
tomatoes | ½ teaspoon chili powder |
| ½ cup chicken broth | ¼ teaspoon black pepper |
| ½ pound precooked ham, diced | ¼ teaspoon salt |
| ½ cup chopped onion | ¼ teaspoon hot sauce |
| ½ cup chopped celery | •••••• |
| ½ cup chopped green pepper | 1 pound precooked shrimp,
peeled and deveined |

Combine rice and 1½ cups water in a metal bowl which will fit loosely in cooker. Cover bowl firmly with aluminum foil. Pour 1 cup water into cooker. Place bowl in steamer basket in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 5 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Open cooker and set rice aside to steam. Remove steamer basket and water.

Add remaining ingredients, except shrimp, to cooker; stir well. Close cover securely. Place pressure regulator on vent pipe and **cook 3 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Stir in shrimp; cook uncovered over medium heat until shrimp is heated through, 2 to 3 minutes. Serve over rice.

Nutrition Information Per Serving

252 Calories, 3 g Fat, 157 mg Cholesterol

6 servings

LEMON 'N DILL COD AND BROCCOLI

- | | |
|--|--|
| 1 pound frozen cod fillets,
1-inch thick
Dill weed
Lemon pepper | Salt
1 cup water
2 cups broccoli, cut into bite
size pieces |
|--|--|

Cut fish into 4 pieces. Sprinkle with dill weed, lemon pepper, and salt. Pour 1 cup water into cooker. Position trivet in cooker. Arrange fish and broccoli in steamer basket on trivet. Close cover securely. Place pressure regulator on vent pipe and **cook 2 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.**

Nutrition Information Per Serving

103 Calories, 1 g Fat, 49 mg Cholesterol

4 servings

SEAFOOD GUMBO

- | | |
|---|---|
| 1 cup long grain white rice | 2 cloves garlic, minced |
| 1½ cups water | 2 bay leaves |
| 1 cup water | 2 tablespoons parsley |
| •••••••• | 1 teaspoon basil |
| 2½ cups chicken broth | ½ teaspoon thyme |
| 1 pound medium, fresh shrimp
peeled and deveined | ¼ teaspoon ground red pepper |
| 1 pound sole fillets, cut into
2-inch pieces | ¼ teaspoon salt |
| 1 can (14-15 ounces) diced
tomatoes | •••••••• |
| 1 cup chopped onion | ¼ cup cold water |
| ¾ cup chopped green pepper | 2 tablespoons cornstarch |
| | 1 package (10 ounces) frozen
sliced okra, thawed |

Combine rice and 1½ cups water in a metal bowl which will fit loosely in cooker. Cover bowl firmly with aluminum foil. Pour 1 cup water into cooker. Place bowl in steamer basket in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 5 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Open cooker and set rice aside to steam. Remove steamer basket and water.

Add broth, shrimp, sole, tomatoes, onion, green pepper, garlic, bay leaves, parsley, basil, thyme, red pepper, and salt to cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 1 minute with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Combine water and cornstarch. Stir into hot mixture. Heat until sauce thickens, stirring constantly. Stir in okra. Heat for 3 to 4 minutes. Discard bay leaf. Serve over rice.

Nutrition Information Per Serving

224 Calories, 2 g Fat, 101 mg Cholesterol

9 servings

MARINATED TUNA

1 pound tuna steak, 1 inch thick	2 cloves garlic, minced
¼ cup lemon juice	1 teaspoon ginger
2 tablespoons olive oil	½ teaspoon black pepper
1 tablespoon soy sauce	½ cup water

Place tuna steaks in a shallow glass dish. Combine remaining ingredients except water; pour over tuna. Marinate for 30 minutes, turning fish once. Remove tuna from marinade and place tuna in steamer basket. Position trivet in cooker. Pour marinade and water into cooker. Place tuna steaks in steamer basket on trivet. Close cover securely. Place pressure regulator on vent pipe and **cook 2 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.**

Nutrition Information Per Serving

4 servings

170 Calories, 6 g Fat, 52 mg Cholesterol

SEAFOOD TIMETABLE

Pour 1 cup water into cooker. Position trivet in cooker. Place seafood in steamer basket on trivet. Do not fill cooker over $\frac{2}{3}$ full. Close cover securely. Place pressure regulator on vent pipe and **cook according to chart with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.**

SEAFOOD (Fresh or thawed)	COOKING TIME
Crab Legs	0 to 1 minute
Fish Fillets (1-inch thick)	2 minutes
Salmon Fillets (1-inch thick)	2 minutes
Scallops Large	1 minute
Shrimp Medium to Large (36 to 40 count)	0 to 1 minute
Large (21 to 25 count)	1 minute
Tuna Fillets (1-inch thick)	2 minutes

POULTRY

A host of great, light meals can evolve from chicken and other poultry when prepared in the pressure cooker. Be it a tender fillet with a delightful, light sauce or a savory casserole with a host of nutritious vegetables, you'll find the pressure cooker is perfect for preparing your favorites in a hurry.

Try the following recipes and enjoy tasty poultry in a variety of ways or prepare your own favorite poultry dishes. It's not necessary to brown poultry before pressure cooking, but you may do so if you like. Searing tends to seal in the natural juices, while cooking without browning lets the flavor of the various ingredients intermingle for some spectacular taste combinations. For crispier chicken, you may want to put the chicken under the broiler for a few minutes after pressure cooking.

*FOR POULTRY, DO NOT FILL PRESSURE COOKER OVER 2/3 FULL!
NO PORTION OF THE POULTRY SHOULD EXTEND ABOVE
THE 2/3 FULL MARK (SEE PAGE 5).*

*OPERATING THE COOKER WITHOUT COOKING LIQUID OR
ALLOWING THE COOKER TO BOIL DRY WILL DAMAGE THE COOKER.*

CHICKEN BREASTS TARRAGON

1 tablespoon vegetable oil	1/4 cup sliced carrot
4 boneless, skinless chicken breast halves	1 teaspoon tarragon
1/2 cup white wine	1 teaspoon salt
Worcestershire sauce	1/4 teaspoon black pepper
1/2 cup white wine	••••••••
1/4 cup chopped onion	1/4 cup water
1/4 cup sliced celery	1 tablespoon cornstarch

Pour oil into cooker. Turn heat selector to medium and brown chicken. Add remaining ingredients except cornstarch and water. Close cover securely. Place pressure regulator on vent pipe and **cook 4 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Remove chicken and keep warm. Combine water and cornstarch. Stir into sauce. Heat until sauce thickens, stirring constantly.

Nutrition Information Per Serving

219 Calories, 5 g Fat, 69 mg Cholesterol

4 servings

CALIFORNIA CHICKEN

2 tablespoons vegetable oil	1/2 cup chicken broth
6 boneless, skinless chicken breast halves	1/4 cup chopped parsley
1 teaspoon rosemary	••••••••
3 cloves garlic, peeled and sliced	1/2 lemon, thinly sliced
1/2 cup white wine	Salt and pepper to taste

Pour oil into cooker. Turn heat selector to medium and brown chicken. Season chicken with rosemary. Place chicken in cooker. Cover chicken with garlic. Combine wine, broth, and parsley; pour over chicken. Close cover securely. Place pressure regulator on vent pipe and **cook 4 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Garnish chicken with lemon slices.

Nutrition Information Per Serving

191 Calories, 6 g Fat, 69 mg Cholesterol

6 servings

CHUTNEY CHICKEN

6 boneless, skinless chicken breast halves	1/3 cup mango chutney
1 can (14-15 ounces) diced tomatoes	1 tablespoon vinegar
1 can (4 ounces) chopped green chillies	1 tablespoon brown sugar
1/2 cup raisins	1 teaspoon allspice
	••••••
	1/4 cup water
	1 tablespoon cornstarch

Place all ingredients except cornstarch and water in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 4 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Remove chicken and keep warm. Combine water and cornstarch. Stir into sauce. Heat until sauce thickens, stirring constantly.

Nutrition Information Per Serving

258 Calories, 3 g Fat, 73 mg Cholesterol

6 servings

SOY CHICKEN

4 boneless, skinless chicken breast halves	1/2 cup sliced mushrooms
1/2 cup water	1/2 onion, sliced
1/2 cup low sodium soy sauce	1/2 cup sliced celery
	3 tablespoons brown sugar

Place all ingredients in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 4 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.**

Nutrition Information Per Serving

169 Calories, 2 g Fat, 69 mg Cholesterol

4 servings

SWEET 'N SOUR CHICKEN WINGS

18 chicken wings	1/4 cup brown sugar
1 can (8 ounces) pineapple chunks, undrained	2 tablespoons soy sauce
1 red pepper, cut into 1-inch pieces	1 tablespoon catsup
1 medium onion, cut into 1-inch pieces	1/2 teaspoon Worcestershire sauce
1/2 cup sliced celery	1/4 teaspoon ground ginger
1/3 cup vinegar	••••••
	2 tablespoons cold water
	2 tablespoons cornstarch

Place chicken wings, pineapple chunks and juice, pepper, onion, and celery in cooker. Mix vinegar, brown sugar, soy sauce, catsup, Worcestershire sauce, and ginger in small bowl; pour into cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 3 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Remove chicken, pineapple, and vegetables to a warm platter. Mix cold water and cornstarch. Stir into hot liquid. Heat until sauce thickens, stirring constantly. Pour sauce over chicken, pineapple, and vegetables. Serve with steamed rice, if desired, see page 32.

Nutrition Information Per Serving

418 Calories, 24 g Fat, 113 mg Cholesterol

6 servings

NOTE: DO NOT INCREASE THIS RECIPE

CHICKEN CACCIATORE

- | | |
|--|-------------------------------------|
| 3 pound chicken, cut into
serving pieces | 2 cloves garlic, minced |
| 1 cup diced tomatoes | 2 tablespoons minced parsley |
| $\frac{1}{3}$ cup white wine | 1 tablespoon oregano |
| 1 $\frac{1}{2}$ cups sliced onions | 1 teaspoon salt |
| $\frac{1}{2}$ cup chopped carrots | $\frac{1}{4}$ teaspoon black pepper |
| $\frac{1}{2}$ cup chopped celery | •••••• |
| | 1 can tomato paste |

Place all ingredients except tomato paste in pressure cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 8 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Place chicken on warm platter. Stir tomato paste into sauce in cooker. Simmer until thickened. Pour over chicken.

Nutrition Information Per Serving

291 Calories, 14 g Fat, 90 mg Cholesterol

6 servings

HERBED CHICKEN

- | | |
|--|--|
| 1 tablespoon vegetable oil | 1 teaspoon oregano |
| 1 cup chopped onion | 1 teaspoon basil |
| 1 tablespoon chopped garlic | •••••• |
| 3 pounds chicken thighs,
skinned | 1 can (4 ounces) sliced
black olives |
| 1 cup chicken broth | 2 tablespoons cold water |
| 1 tablespoon chopped parsley | 2 tablespoons flour |
| $\frac{1}{2}$ cup chopped celery leaves | Salt and pepper to taste |

Pour oil into cooker. Turn heat selector to medium and sauté onion and garlic; remove. Brown chicken. Add onion, garlic, broth, parsley, celery leaves, oregano, and basil. Close cover securely. Place pressure regulator on vent pipe and **cook 8 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Remove chicken to a warm dish. Add olives to liquid and heat. Mix cold water with flour. Stir into hot broth. Heat until sauce thickens, stirring constantly. Pour sauce over chicken.

Nutrition Information Per Serving

250 Calories, 8 g Fat, 115 mg Cholesterol

6 servings

BAYOU BOUNTY CHICKEN

- | | |
|---|--|
| 3 pound chicken, cut into
serving pieces | $\frac{1}{2}$ cup chopped celery |
| 1 can (28 ounces) whole
tomatoes, undrained, cut up | 2 cloves garlic, minced |
| 1 $\frac{1}{2}$ cups chopped onion | 1 tablespoon extra-spicy
seasoning blend |
| $\frac{1}{2}$ cup chopped green pepper | •••••• |
| | Hot cooked rice (see page 31) |

Add all ingredients except rice to pressure cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 8 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Serve chicken and sauce over rice.

Nutrition Information Per Serving

394 Calories, 14 g Fat, 90 mg Cholesterol

6 servings

TURKEY BREAST

- | | |
|---|--|
| <p>3-4 pound turkey breast
 1 tablespoon vegetable oil
 1½ cups water
 1 onion, chopped</p> | <p>½ cup chopped celery
 ½ teaspoon poultry seasoning
 Salt and pepper to taste</p> |
|---|--|

Pour oil into cooker. Turn heat selector to medium and brown turkey on all sides. Add remaining ingredients. Close cover securely. Place pressure regulator on vent pipe and **cook 35 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Thicken gravy, if desired.

Nutrition Information Per Serving 6 to 8 servings
 197 Calories, 8 g Fat, 76 mg Cholesterol

ARROZ CON POLLO

- | | |
|--|--|
| <p>1 (3 to 3½-pound) chicken, cut into serving pieces
 Paprika
 Salt and pepper
 2 tablespoons olive oil
 2 medium onions, chopped
 1 clove garlic, minced
 1 cup chicken broth
 1 bay leaf
 ½ teaspoon crushed red pepper
 ¼ teaspoon crushed saffron threads</p> | <p>•••••••
 1 package (10 ounces) frozen green peas
 1 cup sliced green olives
 1 tomato, peeled, chopped
 1 jar (4 ounces) pimientos, drained, sliced
 •••••••
 Hot cooked rice, (see page 31)</p> |
|--|--|

Sprinkle chicken with paprika, salt, and pepper. Pour oil into pressure cooker. Turn heat selector to medium and brown chicken, a few pieces at a time, and remove. Add onions and garlic to pressure cooker. Sauté until tender. Return chicken to pressure cooker. Add broth, bay leaf, red pepper, and saffron. Close cover securely. Place pressure regulator on vent pipe and **cook 8 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Stir in peas, olives, tomato, and pimientos. Close cover securely. Place pressure regulator on vent pipe and **cook 0 minutes. Let pressure drop of its own accord.** Stir in cooked rice.

Nutrition Information Per Serving 6 servings
 462 Calories, 19 g Fat, 93 mg Cholesterol

POULTRY TIMETABLE

It is not necessary to brown poultry before pressure cooking, but you may do so if you like. After browning, remove poultry from cooker and pour liquid into cooker. Position trivet in cooker. Place poultry in steamer basket on trivet.*

(Note: If the amount of poultry is increased, it is not necessary to increase the cooking time or liquid.)

***Omit trivet if meat extends above the ⅔ full mark.**

*DO NOT FILL PRESSURE COOKER OVER ⅔ FULL!
 NO PORTION OF THE POULTRY SHOULD EXTEND
 ABOVE THE ⅔ FULL MARK (SEE PAGE 5).*

POULTRY	CUPS OF LIQUID	COOKING TIME (MINUTES)	POULTRY	CUPS OF LIQUID	COOKING TIME (MINUTES)
Whole Chicken (2½ to 3 pounds)	1	13 to 15	Chicken Breast (boneless)	1	3 to 4*
Chicken (cut into serving pieces)	1	8	Turkey Breast (3 to 4 pounds)	1½	35

*Cool cooker at once (see page 4).

MEATS

When it comes to creating juicy, tender, flavorful meat dishes, the pressure cooker has no equal. Even budget cuts of meat that usually require slow, moist-heat cooking will turn out succulent and savory—in very little time in the pressure cooker.

An important step when preparing meat in the pressure cooker is to sear meat to a crispy brown on all sides to seal in natural juices. The following recipes were written for fresh or completely thawed meats. To cook frozen meats, thaw one half hour or more so that the surface of the meat will sear crispy brown. Then increase the cooking times given in the recipes. Frozen beef, veal, and lamb should be cooked 25 minutes per pound. Frozen pork should be cooked 30 minutes per pound.

Cooking time will vary depending on the size and thickness of the cut, the distribution of fat and bone, the grade and cut of the meat, and the degree of doneness desired.

After cooking, if gravy is desired, stir 1 to 2 tablespoons of flour or cornstarch into $\frac{1}{4}$ cup cold water. Heat cooking liquid in pressure cooker and slowly pour in flour mixture, stirring to blend. Heat to boiling, stirring constantly for 1 minute or until thickened. Season with salt and pepper.

*FOR MEAT, DO NOT FILL PRESSURE COOKER
OVER $\frac{2}{3}$ FULL! NO PORTION OF THE MEAT SHOULD
EXTEND ABOVE THE $\frac{2}{3}$ FULL MARK (SEE PAGE 5).*

*OPERATING THE COOKER WITHOUT COOKING LIQUID OR
ALLOWING THE COOKER TO BOIL DRY WILL DAMAGE THE COOKER.*

BEEF POT ROAST

3 pounds beef pot roast	Salt and pepper
1 tablespoon vegetable oil	1 onion, minced
2 cups water	1 bay leaf

Pour oil into cooker. Turn heat selector to medium and brown roast well on all sides; remove roast. Pour water into cooker. Position trivet in cooker. Place roast in steamer basket on trivet*. Season roast with salt, pepper, onions, and bay leaf. Close cover securely. Place pressure regulator on vent pipe and **cook 45 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Thicken gravy, if desired.

*Omit trivet if roast extends above the $\frac{2}{3}$ full mark.

Nutrition Information Per Serving
297 Calories, 20 g Fat, 72 mg Cholesterol

6 servings

PORCUPINE MEATBALLS

1 pound lean ground beef	$\frac{1}{4}$ cup sliced celery
$\frac{1}{3}$ cup uncooked long-grain white rice	$\frac{1}{4}$ cup chopped green pepper
2 tablespoons tomato paste	1 cup tomato sauce
1 teaspoon salt	$\frac{1}{2}$ cup water
$\frac{1}{4}$ teaspoon pepper	1 tablespoon sugar
$\frac{1}{2}$ cup chopped onion	$\frac{1}{2}$ tablespoon dry mustard

Combine ground beef, rice, tomato paste, salt, and pepper; mix well. Form into 8 balls. Place meatballs in cooker. Add onion, celery, and green pepper. Combine tomato sauce, water, sugar, and mustard. Pour over meatballs. Close cover securely. Place pressure regulator on vent pipe and cook 12 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.

Nutrition Information Per Serving
350 Calories, 17 g Fat, 77 mg Cholesterol

4 servings

SWISS STEAK

- | | |
|---|-----------------------------------|
| 2 pounds round steak, 1-inch thick | ½ cup chopped green pepper |
| 1 can (8 ounces) tomato sauce | ½ cup sliced celery |
| ½ cup water | ½ teaspoon salt |
| 1 cup chopped onion | ¼ teaspoon pepper |

Place all ingredients in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 18 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Thicken sauce, if desired.

Nutrition Information Per Serving

251 Calories, 9 g Fat, 99 mg Cholesterol

6 servings

BEEF STEW

- | | |
|---|--------------------------------|
| 1 pound lean beef, cut into 1-inch cubes | 1 cup sliced carrots |
| 1 cup water | 1 cup diced tomatoes |
| 1 large onion, sliced | 1 teaspoon salt |
| •••••••• | ¼ teaspoon black pepper |
| 4 small potatoes, quartered | ¼ cup cold water |
| 1 cup frozen green beans | 1 tablespoon flour |

Place beef, water, and onion in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 8 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.**

Add potatoes, green beans, carrots, tomatoes, salt, and pepper to cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 3 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.**

Mix water and flour; stir into stew. Heat until stew thickens, stirring constantly.

Nutrition Information Per Serving

347 Calories, 7 g Fat, 73 mg Cholesterol

4 servings

SPAGHETTI MEAT SAUCE

- | | |
|---|--------------------------------------|
| 1 pound lean ground beef | 1 teaspoon salt |
| 1 can (14 to 15 ounces) diced tomatoes | 1 teaspoon parsley flakes |
| ½ cup cold water | ½ teaspoon oregano |
| 1 cup chopped onion | ½ teaspoon basil |
| ½ cup chopped celery | ¼ teaspoon thyme |
| ½ cup diced green pepper | ⅛ teaspoon red pepper |
| 1 clove garlic, minced | 3 drops hot pepper sauce |
| 2 teaspoons sugar | •••••••• |
| | 1 can (6 ounces) tomato paste |

Turn heat selector to medium and brown beef. Stir in remaining ingredients except tomato paste. Close cover securely. Place pressure regulator on vent pipe and **cook 8 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Stir in tomato paste and simmer, uncovered, to desired thickness. Serve sauce over spaghetti. Sprinkle with Parmesan cheese, if desired.

Nutrition Information Per Serving

229 Calories, 12 g Fat, 51 mg Cholesterol

6 servings

APRICOT BARBECUE PORK ROAST

3 pound boneless rolled pork roast	¼ cup packed dark brown sugar
½ cup catsup	1 teaspoon crushed red pepper
½ cup teriyaki sauce	1 teaspoon dry mustard
⅓ cup apricot preserves	¼ teaspoon black pepper
¼ cup cider vinegar	1 large onion, sliced
	2 cups water

Place pork roast in a large plastic bag or glass dish. Combine catsup, teriyaki sauce, preserves, vinegar, brown sugar, red pepper, mustard, and pepper. Mix thoroughly and pour over pork. Refrigerate overnight. Remove pork; reserve marinade. Brown pork on all sides in pressure cooker over medium heat; remove.

Position trivet, half of sliced onion, and water in cooker. Place pork roast in steamer basket on trivet and arrange remaining onion evenly on top of roast. Close cover securely. Place pressure regulator on vent pipe and **cook 60 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Place reserved marinade in saucepan and simmer until thickened, stirring occasionally. Remove roast and onions from pressure cooker. Add onions to thickened marinade and serve with sliced pork. Onions may be puréed before adding to sauce and served with rice, if desired.

Nutrition Information Per Serving
332 Calories, 13 g Fat, 77 mg Cholesterol

8 servings

BARBECUE SPARERIBS

3 pounds spareribs, cut into serving pieces	½ cup vinegar
1 cup water ••••••	¼ cup chopped onion
1 cup catsup	¼ cup sugar
½ cup water	1 teaspoon salt
	1 teaspoon chili powder
	1 teaspoon celery seed

Place ribs and water in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 5 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Drain off liquid. Mix remaining ingredients; pour over ribs in cooker. Stir to coat ribs. Close cover securely. Place pressure regulator on vent pipe and **cook 10 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Remove ribs. Simmer sauce, uncovered, to desired thickness.

Nutrition Information Per Serving
427 Calories, 27 g Fat, 107 mg Cholesterol

6 servings

CORNED BEEF

3 pounds corned beef	1 tablespoon garlic powder
2 cups water	1 bay leaf

Pour 2 cups water into cooker. Position trivet in cooker. Rub garlic powder into all surfaces of corned beef. Place corned beef in steamer basket on trivet⁺. Add bay leaf. Close cover securely. Place pressure regulator on vent pipe and **cook 60 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.**

Note: If seasoning packet is provided with corn beef, use packet and omit bay leaf.

⁺Omit trivet if corned beef extends above the $\frac{2}{3}$ full mark.

Nutrition Information Per Serving
295 Calories, 18 g Fat, 103 mg Cholesterol

6 servings

STUFFED PORK CHOPS

2 tablespoons vegetable oil	½ cup corn
4 1-inch thick boneless pork chops, with deep pocket cut in each	1 cup bran flakes, crushed
1 cup chopped onion	2 tablespoons water
¾ cup chopped celery	½ teaspoon dried sage
	1½ cups water
	Salt and pepper to taste

Pour oil into cooker. Turn heat selector to medium and brown pork chops. Remove from cooker. Sauté onions and celery in cooker. Stir in corn, bran flakes, 2 tablespoons water, and sage; remove from cooker. Stuff pork chops with mixture. Pour 1½ cups water into cooker. Position trivet in cooker. Place pork chops in steamer basket on trivet. Close cover securely. Place pressure regulator on vent pipe and **cook 16 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.**

Nutrition Information Per Serving
430 Calories, 20 g Fat, 133 mg Cholesterol

4 servings

PORK LOIN ROAST

3 pound pork loin roast	Salt and pepper
1 tablespoon vegetable oil	1 onion, sliced
3 cups water	

Pour vegetable oil into cooker. Turn heat selector to medium and brown roast well on all sides. Remove roast from cooker. Pour water into cooker. Position trivet in cooker. Place roast in steamer basket on trivet⁺. Season with salt, pepper, and sliced onion. Close cover securely. Place pressure regulator on vent pipe and **cook 55 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.**

⁺Omit trivet if roast extends above the ⅔ full mark.

Nutrition Information Per Serving
483 Calories, 27 g Fat, 171 mg Cholesterol

6 servings

STUFFED FLANK STEAK

1 tablespoon margarine	½ teaspoon salt
½ cup chopped onion	¼ teaspoon marjoram
½ cup chopped celery	¼ teaspoon thyme
1 clove garlic, minced	⅛ teaspoon black pepper
6 tablespoons beef broth, divided	1 pound flank steak, cut into 2 equal pieces
1 cup bread crumbs	1 cup diced tomatoes

Add margarine to cooker. Turn heat selector to medium and sauté onion, celery, and garlic. Mix in 2 tablespoons of the broth, bread crumbs, salt, marjoram, thyme, and pepper. Spread stuffing mixture on one steak; top with remaining steak. Secure with toothpicks or metal skewers. Place steak in cooker; stir in remaining 4 tablespoons broth and tomatoes. Close cover securely. Place pressure regulator on vent pipe and **cook 18 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.**

Nutrition Information Per Serving
237 Calories, 12 g Fat, 47 mg Cholesterol

4 servings

LAMB STEW

<p>1 pound lamb stew meat, cut into 1-inch cubes</p> <p>1 cup water</p> <p>1 large onion, sliced</p> <p>1 tablespoon Worcestershire sauce</p> <p>1 large clove garlic, minced ••••••••</p>	<p>4 small potatoes, quartered</p> <p>1 cup baby-cut carrots</p> <p>1 teaspoon salt</p> <p>¼ teaspoon black pepper ••••••••</p> <p>¼ cup cold water</p> <p>1 tablespoon flour</p>
---	---

Place lamb, water, onion, Worcestershire sauce, and garlic in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 6 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.**

Add potatoes, carrots, salt, and pepper. Close cover securely. Place pressure regulator on vent pipe and **cook 3 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.**

Mix water and flour thoroughly; stir into stew. Heat until stew thickens, stirring constantly.

Nutrition Information Per Serving

4 servings

315 Calories, 6 g Fat, 74 mg Cholesterol

MEAT TIMETABLE

Brown meat well and remove from cooker. Pour liquid into cooker. Position trivet in cooker. Place meat in steamer basket on trivet.†

(Note: If the amount of meat is increased, it is not necessary to increase the cooking time or liquid.)

†Omit trivet if meat extends above the ⅔ full mark.

DO NOT FILL PRESSURE COOKER OVER ⅔ FULL!
NO PORTION OF THE MEAT SHOULD EXTEND ABOVE THE ⅔ FULL MARK (SEE PAGE 5).

MEAT	CUPS OF LIQUID	COOKING TIME (MINUTES)	MEAT	CUPS OF LIQUID	COOKING TIME (MINUTES)		
BEEF			PORK				
Chuck Roast	3 pounds	2	45 – 50	Chops	1" thick	1	15*
Corned Beef	3 pounds	2	60	Chops	½" thick	1	8*
Rolled Rib Roast	3 pounds	1½	30 – 35	Butt Roast	3 pounds	2	55
Round Steak	1" thick	1	18*	Loin Roast	3 pounds	2	55
Round Steak	½" thick	1	10*	Steak	1" thick	1	12*
Short Ribs		1½	25	Steak	½" thick	1	5*
HAM			VEAL				
Slice	3 pounds	1½	30 – 35	Chops	1" thick	1	12*
Picnic	3 pounds	1½	30 – 35	Chops	½" thick	1	5*
LAMB			Roast	3 pounds	2	45 – 50	
Chops	1" thick	1	12*	Steak	1" thick	1	10*
Chops	½" thick	1	5*				
Leg of Lamb	3 pounds	2½	35 – 45				

* Cool cooker at once (see page 4).

VEGETABLES

Vegetables have assumed new importance and prominence on the menu. Health-conscious cooks feature an abundance of vegetables on the family meal plan, while restaurants increasingly cater to a more “vegetable-conscious” clientele.

Pressure cooking is the preferred method for preparing vegetables. Because of the fast cooking time and super-heated steam, vegetables retain most of their natural color, texture, flavor, and nutrients. And pressure cooking offers an additional health advantage, because so much more natural taste is retained, vegetables require much less salt and seasonings.

A garden variety of fresh or frozen vegetables can be cooked at the same time in the pressure cooker. By using the trivet and steamer basket to keep them out of the cooking liquid, each vegetable retains its own distinctive flavor and appearance. Just be sure that all vegetables cooked together require the same cooking time. It is important to accurately time the cooking period, because vegetables cook very quickly in the pressure cooker. If you wish to blend the vegetable flavors, place them in the steamer basket and omit the trivet.

*FOR FRESH AND FROZEN VEGETABLES,
DO NOT FILL PRESSURE COOKER OVER 2/3 FULL!*

*FOR DRIED VEGETABLES,
DO NOT FILL PRESSURE COOKER OVER 1/2 FULL!*

*OPERATING THE COOKER WITHOUT COOKING LIQUID OR
ALLOWING THE COOKER TO BOIL DRY WILL DAMAGE THE COOKER.*

CABBAGE WITH APPLES

- | | |
|---|---|
| 1/2 small head cabbage, shredded | 1/2 cup chicken broth |
| 1 small onion, thinly sliced | 2 tablespoons frozen apple
juice concentrate, thawed |
| 1 small tart apple, peeled,
cored, and chopped | Salt and pepper to taste |

Add all ingredients to cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 4 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.**

Nutrition Information Per Serving

6 servings

50 Calories, 0 g Fat, 0 mg Cholesterol

GLAZED ROOT VEGETABLES

- | | |
|--|-------------------------------------|
| 2 tablespoons margarine | 2 tablespoons sugar |
| 2 medium turnips, peeled, cut
into eights | 2 teaspoons ground ginger
•••••• |
| 8 ounces baby carrots | 1/4 cup cold water, optional |
| 2 medium parsnips, peeled
sliced 1/2-inch thick | 1 tablespoon cornstarch, optional |
| 1 cup chicken broth | Salt and pepper to taste |

Heat margarine in pressure cooker over medium heat; add turnip wedges and carrots and sauté for 3 minutes. Add parsnips, chicken broth, ginger, and sugar. Close cover securely. Place pressure regulator on vent pipe and **cook 1 minute with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Combine water and cornstarch. Stir into sauce. Heat until sauce thickens, stirring constantly.

Nutrition Information Per Serving

8 servings

77 Calories, 3 g Fat, 0 mg Cholesterol

GARLIC MASHED POTATOES

2 pounds russet potatoes, peeled and diced	•••••••
4 large cloves garlic	1 tablespoon margarine
1½ cups chicken broth	Salt and pepper

Place all ingredients except margarine and salt and pepper in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 5 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Allow potatoes, garlic, and broth to remain in cooker. Mash potatoes using a potato masher or hand mixer until desired consistency is reached. Add margarine.

Nutrition Information Per Serving

6 servings

127 Calories, 4 g Fat, 0 mg Cholesterol

ARTICHOKES 'N SAUCE

1 cup water	3 artichokes
1 tablespoon vegetable oil	

Pour water and oil into cooker. Position trivet in cooker. Place artichokes upside down in steamer basket on trivet. Close cover securely. Place pressure regulator on vent pipe and **cook 10 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Serve with your choice of the following sauces.

Nutrition Information Per Serving

3 servings

60 Calories, 0 g Fat, 0 Cholesterol

GARLIC SAUCE — Combine ¼ cup margarine, melted and 2 cloves minced garlic. Serve warm.

HERB YOGURT — Combine 1 cup plain yogurt, ¼ cup finely chopped carrots, ½ teaspoon dill weed, and ¼ teaspoon salt. Serve chilled.

ITALIAN SAUCE — Combine ½ cup mayonnaise and ¼ cup Italian style salad dressing. Serve chilled.

MAPLE GLAZED SWEET POTATOES

3 sweet potatoes, peeled, cut into 1 to 1½-inch chunks	1 tablespoon melted margarine
¾ cup maple flavored syrup	½ teaspoon salt
½ cup water	

Place sweet potatoes in pressure cooker. Combine remaining ingredients and pour over potatoes. Close cover securely. Place pressure regulator on vent pipe and **cook 5 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.**

Nutrition Information Per Serving

6 servings

125 Calories, 2 g Fat, 0 mg Cholesterol

FRESH AND FROZEN VEGETABLE TIMETABLE

When using the fresh vegetable timetables below and on page 29, cook the vegetables the minimum amount of time indicated if you prefer your vegetables crisp. If you prefer your vegetables soft, cook them the maximum amount of time indicated. **TO PREVENT OVER-COOKING, COOL COOKER AT ONCE AFTER COOKING VEGETABLES, EXCEPT WHEN NOTED.**

If the timetable says to cook 0 minutes, this means to cook food until you hear and/or see a steady flow of steam escaping from the pressure regulator, then cool cooker at once.

Quantity of vegetables does not change pressure cooking times. More mature vegetables may require longer pressure cooking times than given in chart.

To assure even heating, separate a block of frozen vegetables.

For fresh and frozen vegetables, pour liquid into cooker. Position trivet in cooker. Place vegetables in steamer basket on trivet.

*FOR FRESH AND FROZEN VEGETABLES,
DO NOT FILL PRESSURE COOKER OVER 2/3 FULL!*

FRESH VEGETABLE TIMETABLE

VEGETABLE	SIZE	CUPS OF LIQUID	COOKING TIME (MINUTES)	VEGETABLE	SIZE	CUPS OF LIQUID	COOKING TIME (MINUTES)
Artichoke	Whole, 6 to 8 ounces	1	10	Peas	Shelled	1	0 – 2
Asparagus	Stems cut into 1-inch pieces	1	0 – 1	Peppers	Whole	1	0 – 3
Beans (green, wax)	Whole or sliced	1	1 – 3	Potatoes (sweet)	Sliced, 1 to 1½-inches thick	1	6 – 8
Beets	Whole, 2½-inch diameter	1½	15 – 16		Sliced, ½-inch thick	1	4 – 5
Broccoli	Flowerets	1	0 – 2	Potatoes (white)	Whole, 2½-inch diameter	1½	15
Brussels Sprouts	Small, 1-inch diameter)	1	1 – 3		Whole, 1½-inch diameter	1	10
Cabbage (red, green)	Wedges, 2-inch thick	1	3 – 5		Sliced, ¾-inch thick	1	5
	Thinly sliced	1	2 – 3	Rutabaga	Cubes or sliced, 1 inch thick	1	3
Carrots	Baby cut	1	3 – 5	Spinach	Whole leaves	1	0
	½-inch slices	1	3 – 5	Squash (winter) acorn+	Quartered	1	12
Cauliflower	Flowerets	1	0 – 2	Squash (winter) spaghetti+	Halved	1	12
Collards*	Leaves coarsely chopped, stems thinly sliced.	1	3 – 4	Squash (yellow, zucchini)	Sliced, 1-inch thick	1	1
Corn on-the-cob	Whole, 2½-inch diameter	1	3		Sliced, ¼- to ½-inch thick	1	0 – 1
Eggplant	Cubed, 1 to 1½-inches thick	1	2 – 3	Swiss Chard	Whole leaves	1	0 – 1
	Sliced, ½-inch thick	1	2		core, and seeds. Cut up		
Kale	Leaves coarsely chopped, stems thinly sliced	1	1 – 2	Turnips	Sliced or cubed, ¾-inch thick	1	3 – 5
Parsnips	Sliced, ½-inch thick	1	0 – 2				

+ Let pressure drop of its own accord.

* Do not use trivet; place in steamer basket.

FROZEN VEGETABLE TIMETABLE

VEGETABLE	CUPS OF LIQUID	COOKING TIME (MINUTES)	VEGETABLE	CUPS OF LIQUID	COOKING TIME (MINUTES)
Asparagus (cut, spears)	1	2	Corn on Cob	1	2 – 3
Beans (green, wax, french style)	1	1 – 2	Lima Beans	1	1 – 2
Broccoli	1	1 – 2	Mixed Vegetables	1	1 – 2
Brussels Sprouts	1	2 – 3	Peas	1	1 – 2
Cauliflower	1	1 – 2	Peas and Carrots	1	1 – 2
Corn Cut	1	1 – 2	Spinach	1	2 – 4

DRY BEANS AND PEAS

The pressure cooker is ideal for preparing dry beans and peas quickly. However, dry beans and peas have a tendency to froth and foam during cooking, which could cause the vent pipe to become blocked. **Therefore, it is necessary to use the following cautions when pressure cooking dry beans and peas:**

- (1) **Never fill the cooker over the ½ full line (this includes beans, ingredients, and water).**
- (2) **Add 1 tablespoon vegetable oil for cooking.**
- (3) **Allow pressure to drop of its own accord.**

SOAKING BEANS AND PEAS — Soaking is strongly recommended for all beans and peas, except lentils and black-eyed peas, for even cooking and to remove water-soluble, gas-producing starches. Soaking can be done using the traditional or the quick-soak method.

Traditional method: Clean and rinse beans; cover with three times as much water as beans. Soak 4 to 8 hours. Drain.

Quick method: Clean and rinse beans; cover with three times as much water as beans. Bring beans to a boil and boil for 2 minutes. Remove from heat, cover, and let stand for 1 to 2 hours. Drain.

COOKING BEANS AND PEAS — After soaking, rinse beans and remove any loose skins. Place beans in pressure cooker. Add fresh water to just cover the beans and add 1 tablespoon vegetable oil. Close cover securely. Place pressure regulator on vent pipe and cook according to the times in the timetable below. For more firm beans for salads and side dishes and when cooking less than 2 cups of beans or peas, use the shorter time. For soups and stews, use the longer time. **After cooking is complete, allow pressure to drop of its own accord.**

*FOR DRY BEANS AND PEAS,
DO NOT FILL PRESSURE COOKER OVER ½ FULL!
OPERATING THE COOKER WITHOUT COOKING LIQUID OR
ALLOWING THE COOKER TO BOIL DRY WILL DAMAGE THE COOKER.*

DRY BEANS AND PEAS TIMETABLE

Soak beans and peas, except lentils and black-eyed peas, according to information above. **Add 1 tablespoon vegetable oil to cooking liquid. DO NOT COOK SPLIT PEAS.**

FOR DRY BEANS AND PEAS, DO NOT FILL PRESSURE COOKER OVER ½ FULL!

BEANS AND PEAS	COOKING TIME (MINUTES)	BEANS AND PEAS	COOKING TIME (MINUTES)
Adzuki	1 – 3	+ Lima Beans (large)	0 – 1
Anasazi	1 – 3	+ Lima Beans (baby)	1 – 3
Black Beans	2 – 4	Navy Beans (pea)	1 – 3
Black-eyed Peas	2 – 4*	Peas (whole yellow, green)	6 – 9
+ Chickpeas (garbanzo)	7 – 10	Pinto Beans	3 – 6
Great Northern Beans	2 – 5	Red beans	3 – 6
Kidney Beans	1 – 3	Soy beans (beige)	8 – 11
Lentils (brown, green)	3 – 5*		

* cooking time is for unsoaked beans

+ add ½ to 1 teaspoon salt to soaking and cooking water to keep bean skins intact.

LENTIL CURRY

1	tablespoon vegetable oil	1	tablespoon curry powder
1½	cups chopped onion	1	teaspoon ground ginger
6	cups water		••••••
2	cups lentils	1	teaspoon salt
1	tablespoon coriander		

Pour oil into cooker. Turn heat selector to medium and sauté onions. Add water, lentils, coriander, curry powder, and ginger. Close cover securely. Place pressure regulator on vent pipe and cook 3 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord. Stir in salt.

Nutrition Information Per Serving

190 Calories, 2 g Fat, 0 mg Cholesterol

8 servings

BAKED BEANS

2	cups navy beans	1	medium onion, minced
3	cups water	⅓	cup brown sugar
¼	cup catsup	½	teaspoon dry mustard
¼	cup molasses	¼	teaspoon black pepper
1	8-ounce slice uncooked ham, diced		••••••
			Salt to taste

Soak beans according to instructions on page 29. Drain. Add drained navy beans and remaining ingredients except salt to cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 35 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.**

Nutrition Information Per Serving

264 Calories, 4 g Fat, 85mg Cholesterol

6 servings

SAVORY WHITE BEANS

2	cups navy beans	1	small bay leaf
3	cups chicken broth	½	teaspoon thyme
1	cup chopped onion	¼	teaspoon rosemary
1	cup sliced carrots	¼	teaspoon black pepper
1	tablespoon minced garlic		••••••
1	tablespoon vegetable oil		Salt to taste

Soak beans according to instructions on page 29; drain. Add all ingredients except salt to cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 2 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.**

Nutrition Information Per Serving

254 Calories, 3 g Fat, 0 mg Cholesterol

7 servings

GRAINS

Grains are an important, but often little recognized, part of a healthy diet. They contribute complex carbohydrates, soluble and insoluble fiber, and other nutrients. Yet with all these benefits, grains are low in fat. Grains can be prepared quickly and conveniently with the pressure cooker. With a pressure cooker it is not necessary to soak or simmer grains for several hours.

During cooking many grains tend to froth, foam, and sputter and could cause the vent pipe to become blocked. Therefore, to contain frothing and foaming during the cooking period, grains must be prepared in a bowl covered with aluminum foil in the pressure cooker. Preparing grains in a bowl also minimizes cleanup which can be difficult if the grains stick to the bottom of the cooker.

The bowl can be metal, such as stainless steel, or oven-safe glass. If using glass, increase cooking time by 1 to 5 minutes depending on the length of the recommended cooking time.

FOR GRAINS, DO NOT FILL PRESSURE COOKER OVER ½ FULL!

*OPERATING THE COOKER WITHOUT COOKING LIQUID OR
ALLOWING THE COOKER TO BOIL DRY WILL DAMAGE THE COOKER.*

GRAIN TIMETABLE

Combine the desired grain and the amount of water or broth indicated in the table below in a bowl which fits loosely in the pressure cooker. Cover bowl securely with aluminum foil. Pour two cups water into cooker. Place bowl in steamer basket in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook for the time indicated in the table below with a very slow, steady flow of steam escaping from the pressure regulator. After pressure cooking, allow pressure to drop of its own accord.** Using tongs or hot pads, carefully remove bowl from cooker. Remove foil. Before serving, separate the grains by lifting gently with a fork while steaming. It may be necessary to allow excess moisture to evaporate from some grains. If excessive moisture remains, drain before using grains.

FOR GRAINS, DO NOT FILL PRESSURE COOKER OVER ½ FULL!

<u>GRAIN (1 CUP)</u>	<u>CUPS LIQUID IN BOWL</u>	<u>COOKING TIME (MINUTES)</u>	<u>GRAIN (1 CUP)</u>	<u>CUPS LIQUID IN BOWL</u>	<u>COOKING TIME (MINUTES)</u>
Amaranth	1¾	4 – 5	Quinoa	1½	1
Barley (Hulled)	2½	25 – 28	Rice (brown)	1½	10 – 12
Barley (Pearl)	2½	9 – 12	Rice (white)	1½	5 – 8
Buckwheat	2	3 – 4	Rye Berries	1½	20 – 25
Bulgar	1½	2 – 3	Spelt	2	25 – 30
Millet	2	9 – 10	Wheat berries	2	25 – 30
Oats (whole groats)	1½	20 – 25	Wild Rice	1½	20 – 25
Oats (steel cut)	2	4 – 5			

SEASONED RICE PILAF

2 tablespoons margarine	½ teaspoon salt
1 small onion, chopped	½ teaspoon oregano
2 cups long grain white rice	¼ teaspoon pepper
2 cups chicken broth	2 cups water
1¾ cups water	

Place margarine in cooker. Turn heat selector to medium to melt margarine. Add onions; sauté until tender. Combine onion with rice, broth, 1¾ cup water, salt, oregano, and pepper in a metal bowl which will fit loosely in cooker. Cover bowl firmly with aluminum foil. Pour 2 cups water into cooker. Place bowl in steamer basket in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 5 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Open cooker, remove foil, and set rice aside to steam.

Nutrition Information Per Serving

8 servings

210 Calories, 4 g Fat, 0 mg Cholesterol

VARIATION: GRECIAN RICE PILAF

After pressure has dropped of its own accord, combine rice, ¾ cup peas, ½ cup sliced ripe olives, and 1 large red pepper, coarsely chopped. Allow rice to steam uncovered 5 minutes.

STEAMED RICE

1 cup long grain white rice	2 cups water
1½ cups water	

Combine rice and 1½ cups water in a metal bowl which fits loosely in cooker. Cover bowl firmly with aluminum foil. Pour 2 cups water into cooker. Place bowl in steamer basket in cooker. Close cover securely. Place pressure regulator on vent pipe and **COOK 5 MINUTES WITH A VERY SLOW, STEADY FLOW OF STEAM ESCAPING FROM THE PRESSURE REGULATOR.** Let pressure drop of its own accord. Open cooker and allow rice to steam uncovered 5 minutes.

Nutrition Information Per Serving

4 servings

168 Calories, 0 g Fat, 0 Cholesterol

BROWN RICE WITH VEGGIES

1 cup natural brown rice	½ cup sliced green onion
1½ cups chicken stock or broth	1 package (2 ounces) sliced blanched almonds
1 large tomato, peeled, seeded, chopped	2 cups water
½ cup diced carrot	••••••••
½ cup diced celery	¼ cup chopped parsley
½ cup diced green pepper	

Combine rice and chicken stock in a metal bowl which fits loosely in cooker. Stir in vegetables and almonds. Cover bowl firmly with aluminum foil. Pour 2 cups water into cooker. Place bowl in steamer basket in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 10 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Open cooker, remove foil, and set rice aside to steam. Stir in parsley.

Nutrition Information Per Serving

4 servings

290 Calories, 10 g Fat, 0 mg Cholesterol

WILD RICE WITH RAISINS AND PECANS

- | | | | |
|-----------|-------------------------------------|----------|----------------------------|
| 1 | tablespoon vegetable oil | 2 | cups water |
| 1 | medium onion, finely chopped | | ••••••• |
| 1½ | cups wild rice | ¾ | cup golden raisins |
| 2 | cups beef broth | ⅓ | cup pecans, toasted |

Pour oil into cooker. Turn heat selector to medium and sauté onion. Combine onion with wild rice and beef broth in a metal bowl which fits loosely in cooker. Cover bowl firmly with aluminum foil. Pour water into cooker. Place bowl in steamer basket in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 25 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Open cooker and remove aluminum foil; add raisins and allow to steam for 5 minutes. Remove bowl from cooker; stir in pecans.

Nutrition Information Per Serving

167 Calories, 5 g Fat, 0 mg Cholesterol

8 servings

RISOTTO WITH ARTICHOKE HEARTS AND SUN-DRIED TOMATOES

- | | | | |
|----------|------------------------------------|-----------|--|
| 1 | tablespoon olive oil | 1 | can (13¾ ounces) artichoke hearts, drained and coarsely chopped |
| 1 | cup arborio rice | ¼ | cup grated Parmesan cheese |
| 2 | cloves garlic, minced | 1½ | tablespoons fresh thyme or 1½ teaspoons dried thyme |
| 2 | cups chicken broth | | Salt and pepper to taste |
| ⅓ | cup white wine | | |
| ⅓ | cup dried tomatoes, chopped | | |
| 2 | cups water | | |
| | ••••••• | | |

Heat oil in pressure cooker over medium heat; add rice and stir for 2 minutes until coated and slightly translucent. Add garlic and cook for 1 minute. Combine rice, garlic, broth, white wine, and tomatoes in a metal bowl which fits loosely in cooker. Cover bowl firmly with aluminum foil. Pour water into cooker. Place bowl in steamer basket in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 8 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.** Open cooker and remove foil. Stir artichoke hearts, Parmesan cheese, and thyme into rice.

Nutrition Information Per Serving

220 Calories, 5 g Fat, 4 mg Cholesterol

4 servings

DESSERTS

Add a fabulous finale to any meal with desserts prepared in your pressure cooker. Pressure cooking gives an even texture to pudding and a satiny feel to custards.

Desserts may be prepared in oven-safe custard cups or any metal mold which will fit loosely in the steamer basket in the pressure cooker. Fill molds only $\frac{2}{3}$ full to allow for expansion of food. Cover securely with aluminum foil shaped to the sides of the mold. Place the steamer basket in the cooker. Then place the mold or custard cups in the steamer basket. Up to four custard cups of dessert can be pressure cooked at a time. Place two custard cups in the steamer basket. Then, stack the other two custard cups opposite the bottom two custard cups.

To test custards for doneness, insert a knife into the center. If the knife comes out clean, it is done. If not, it will be necessary to bring the cooker back up to pressure and cook the custard a minute or two longer.

Do not cook applesauce, cranberries, or rhubarb in the pressure cooker.

*FOR DESSERTS, DO NOT FILL
PRESSURE COOKER OVER $\frac{2}{3}$ FULL!*

*OPERATING THE COOKER WITHOUT COOKING LIQUID OR
ALLOWING THE COOKER TO BOIL DRY WILL DAMAGE THE COOKER.*

STUFFED APPLES

$\frac{1}{4}$ cup golden raisins	$\frac{1}{2}$ teaspoon ground cinnamon
$\frac{1}{2}$ cup dry red wine	4 cooking apples
$\frac{1}{4}$ cup chopped nuts	1 tablespoon butter
2 tablespoons sugar	1 cup water
$\frac{1}{2}$ teaspoon grated orange rind	

Soak raisins in wine for at least 30 minutes. Drain, reserving wine. Combine raisins, nuts, sugar, orange rind, and cinnamon. Core apples, cutting to but not through bottoms. Peel top one-third of apples. Place each apple on square of aluminum foil that is large enough to completely wrap apple. Fill centers with raisin mixture. Top each with one-fourth of the butter. Wrap foil around apple, pinching firmly together at top. Place reserved wine, water, and apples in cooker. Place pressure regulator on vent pipe and **cook 10 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.**

Nutrition Information Per Serving

224 Calories, 8 g Fat, 8 mg Cholesterol

4 servings

RICE PUDDING

1 cup long-grain white rice	1 cup whole milk
$1\frac{1}{2}$ cups water	$\frac{1}{2}$ teaspoon sugar
1 cup water	$\frac{1}{2}$ cups water raisins
••••••	$\frac{1}{2}$ teaspoon cinnamon

Combine rice and $1\frac{1}{2}$ cups water in a metal bowl which fits loosely in cooker. Cover bowl firmly with aluminum foil. Pour 1 cup water into cooker. Place bowl in steamer basket in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 10 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Stir milk, sugar, raisins, and cinnamon into rice. Cover bowl firmly with aluminum foil. Place bowl in steamer basket in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 3 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Let pressure drop of its own accord.**

Nutrition Information Per Serving

238 Calories, 2 g Fat, 24 mg Cholesterol

6 servings

VANILLA CUSTARD

2 cups lowfat milk	½ teaspoon vanilla
4 eggs, slightly beaten	Nutmeg
¼ cup sugar	1 cup water
¼ teaspoon salt	

Combine milk, eggs, sugar, salt, and vanilla. Pour into individual custard cups. Sprinkle nutmeg on custards. Cover each cup firmly with aluminum foil. Pour water into cooker. Place custard cups in steamer basket in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 5 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Chill.

Nutrition Information Per Serving

4 servings

137 Calories, 4 g Fat, 118 mg Cholesterol

VARIATION: COCONUT CUSTARD

Sprinkle 1 tablespoon coconut over top of each vanilla custard before cooking.

PETITE PUMPKIN CUSTARDS

1 can (16 ounces) solid-pack pumpkin	1 teaspoon finely chopped candied ginger, optional
1 can (14 ounces sweetened condensed milk)	¼ teaspoon ground cloves
3 eggs, beaten	1 cup water
1 teaspoon ground cinnamon	••••••
	Whipped cream, optional

Mix pumpkin, milk, eggs, cinnamon, ginger, and cloves. Pour into individual custard cups. Cover each cup firmly with aluminum foil. Pour water into cooker. Place custard cups in steamer basket in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 10 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Refrigerate until chilled. Serve with whipped cream, if desired.

Nutrition Information Per Serving

8 servings

207 Calories, 6 g Fat, 97 mg Cholesterol

TAPIOCA PUDDING

2 cups lowfat milk	⅓ cup sugar
2 tablespoons quick cooking tapioca	½ teaspoon vanilla
2 eggs, slightly beaten	1 cup water

Scald milk and tapioca. Remove from heat and let stand 15 minutes. Combine eggs, sugar, and vanilla. Add milk and tapioca, stirring constantly. Pour into individual custard cups. Cover firmly with aluminum foil. Pour water into cooker. Place custard cups in steamer basket in cooker. Place pressure regulator on vent pipe and **cook 5 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Chill.

Nutrition Information Per Serving

6 servings

113 Calories, 3 g Fat, 75 mg Cholesterol

OATMEAL APPLE CRISP

4 cups apples, peeled and sliced	2 tablespoons flour
1 tablespoon lemon juice	1 teaspoon cinnamon
½ cup quick cooking oats	2 tablespoons margarine, softened
¼ cup brown sugar	1 cup water

Sprinkle apples with lemon juice. Combine oats, brown sugar, flour, and cinnamon. Cut in margarine until coarse meal forms. Place apples in a greased bowl that will loosely fit in cooker. Sprinkle oat mixture evenly over apples. Cover bowl firmly with aluminum foil. Pour water into cooker. Place bowl in steamer basket in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 20 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.**

Nutrition Information Per Serving
209 Calories, 7 g Fat, 0 Cholesterol

4 servings

CHEESECAKE

1 8-ounce package cream cheese	2 eggs
1 3-ounce package cream cheese	½ cup vanilla wafer crumbs
½ cup sugar	2½ cups water

Beat cream cheese until smooth. Add sugar and beat in eggs. Pour mixture into buttered custard cups. Top with vanilla wafer crumbs. Cover each cup firmly with aluminum foil. Pour water into cooker. Place custard cups in steamer basket in cooker. Close cover securely. Place pressure regulator on vent pipe and **cook 15 minutes with a very slow, steady flow of steam escaping from the pressure regulator. Cool cooker at once.** Cool cheesecake. Cut around inside of cups to loosen and invert onto serving dish. Chill. Top with one of the following sauces, if desired.

Nutrition Information Per Serving
305 Calories, 23 g Fat, 157 Cholesterol

6 servings

CARAMEL SAUCE — Combine ¼ cup soft cream cheese, ¼ cup brown sugar, 1 tablespoon granulated sugar, and ¼ teaspoon vanilla. Mix thoroughly. Spoon over cheesecake. Garnish with pecans. Refrigerate until serving.

FRUIT SAUCE — Spoon canned fruit pie filling of your choice over cheesecake. Refrigerate until serving.

RECIPE INDEX

SOUPS AND STOCKS 10

- Beef Tomato Soup 11
- Black Bean Soup 11
- Brown Beef Soup 11
- Brown Beef Soup Stock 11
- Chicken Dumpling Soup 10
- Chicken Noodle Soup 10
- Chicken Rice Soup 10
- Chicken Soup 10
- Chicken Soup Stock 10
- Minestrone 12
- Onion Soup 11
- Potato Soup 12
- Saffron Fish Stew 12
- Zesty Homemade Chili 13

SEAFOOD 13

- Lemon 'N Dill Cod and
Broccoli 15
- Marinated Tuna 16
- Salmon Steaks Moutarde 13
- “Scampi Style” Shrimp 14
- Seafood Gumbo 15
- Seafood Timetable 16
- Shrimp Jambalaya 14

POULTRY 17

- Arroz Con Pollo 20
- Bayou Bounty Chicken 19
- California Chicken 17

POULTRY (Continued)

- Chicken Breasts Tarragon 17
- Chicken Cacciatore 19
- Chutney Chicken 18
- Herbed Chicken 19
- Poultry Timetable 20
- Soy Chicken 18
- Sweet 'N Sour Chicken Wings . . . 18
- Turkey Breast 20

MEATS 21

- Apricot Barbecue Pork Roast . . . 23
- Barbecue Spareribs 23
- Beef Pot Roast 21
- Beef Stew 22
- Corned Beef 23
- Lamb Stew 25
- Meat Timetable 25
- Porcupine Meatballs 21
- Pork Loin Roast 24
- Spaghetti Meat Sauce 22
- Stuffed Flank Steak 24
- Stuffed Pork Chops 24
- Swiss Steak 22

VEGETABLES 26

- Artichokes 'N Sauce 27
- Cabbage with Apples 26
- Fresh Vegetable Timetable 28
- Frozen Vegetable Timetable 29

VEGETABLES (Continued)

- Garlic Mashed Potatoes 27
- Glazed Root Vegetables 26
- Maple Glazed Sweet Potatoes . . . 27

DRIED BEANS AND PEAS 29

- Baked Beans 30
- Dried Beans and Peas Timetable . 29
- Lentil Curry 30
- Savory White Beans 30

GRAINS 31

- Brown Rice with Veggies 32
- Grain Timetable 31
- Grecian Rice Pilaf 32
- Risotto with Artichoke Hearts
and Sun-Dried Tomatoes 33
- Seasoned Rice Pilaf 32
- Wild Rice with Raisins
and Pecans 33

DESSERTS 34

- Cheesecake 36
- Coconut Custard 35
- Oatmeal Apple Crisp 36
- Petite Pumpkin Custards 35
- Rice Pudding 34
- Stuffed Apples 34
- Tapioca Pudding 35
- Vanilla Custard 35

SERVICE AND PARTS INFORMATION

If you have any questions regarding the operation of your Presto® cooker or need parts for your cooker, contact us by any of these methods:

- **Call 1-800-877-0441** weekdays 8:00 AM to 4:30 PM (Central Time)
- **Email us at our website www.GoPresto.com**
- **Write: NATIONAL PRESTO INDUSTRIES, INC.**
Consumer Service Department
3925 N. Hastings Way, Eau Claire, WI 54703-3703

Inquiries will be answered promptly by telephone, letter, or email. When writing, please include a phone number and a time when you can be reached during weekdays, if possible.

When contacting the Consumer Service Department or when ordering replacement parts, please specify the model number and date code found stamped on the side of the cooker body.

Please record this information:

Model Number _____ Date Code _____ Date Purchased _____

Any maintenance required for this cooker, other than that described in the Care and Maintenance section of this book (pages 6 and 7), should be performed by our Factory Service Department. Be sure to indicate date of purchase and a description of the problem when sending a cooker for repair. **Send cookers for repair to:**

CANTON SALES AND STORAGE COMPANY
Presto Factory Service Department
555 Matthews Drive, Canton, MS 39046-0529

The Presto Factory Service Department is equipped to service all PRESTO® appliances and supply genuine PRESTO® parts. Genuine PRESTO® replacement parts are manufactured to the same exacting quality standards as PRESTO® appliances and are engineered specifically to function properly with its appliances. Presto can only guarantee the quality and performance of genuine PRESTO® parts. "Look-alikes" might not be of the same quality or function in the same manner. To ensure that you are buying genuine PRESTO® replacement parts, look for the PRESTO® trademark.

Cooker replacement parts may also be available at hardware stores and other retail outlets. Parts may also be ordered on-line at www.GoPresto.com.

PRESTO® Limited Warranty

This quality PRESTO® appliance is designed and built to provide many years of satisfactory performance under normal household use. Presto pledges to the original owner that should there be any defects in material or workmanship during the first twelve (12) years after purchase, we will repair or replace it at our option. Our pledge does not apply to damage caused by shipping. To obtain service under the warranty, return this PRESTO® product, shipping prepaid to the Factory Service Department. California residents may deliver this PRESTO® product to their nearest PRESTO® Authorized Service Station. When returning a product, please include a description of the defect and indicate the date the appliance was purchased.

We want you to obtain maximum enjoyment from using this PRESTO® appliance and ask that you read and follow the instructions enclosed. Failure to follow instructions, damage caused by improper replacement parts, abuse or misuse will void this pledge. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This is Presto's personal pledge to you and is being made in place of all other express warranties.

NATIONAL PRESTO INDUSTRIES, INC.
Eau Claire, Wisconsin 54703-3703