

PRESTO®

www.GoPresto.com

easy store electric Egg Cooker



- Makes hard-, medium-, and soft-boiled eggs. Poaches eggs too!
- Cooks medium, large, extra-large, and jumbo eggs.
- Removable tray and cover for storing cooked eggs in fridge.

Easy egg storage!



12
EGG
CAPACITY



Cover, two poaching trays, boiling tray, and water reservoir.



Dual poaching trays steam up to four eggs at the same time.

- **Easy-to-use egg cooker.** Boiled or poached—use the measuring cup to fill the water reservoir with water, select tray, add eggs, cover, and plug in.
- **Includes** electric base with nonstick surface, 12-egg boiling tray, two poaching trays, water measuring cup, and transparent cover.
- **Measuring cup features markings** that specify the amount of water needed for making hard-, medium-, and soft-boiled eggs, as well as poached eggs.
- **Light and buzzer** signal when eggs are done.
- **Easy to clean.** Boiling tray and poaching trays are dishwasher safe.
- **Cord wraps in base;** parts nest for compact storage.



Stock No. **04633**
120 volts AC, 500 watts