


ELECTRONIC BIG DIGITAL TIMER OPERATING INSTRUCTIONS

INSERT BATTERY BEFORE USING

1. Remove the battery compartment cover on the back of the unit by sliding it in the direction of the arrow (Fig. A).
2. Insert one AAA battery into the compartment matching the + and - symbols as indicated inside the battery compartment.
3. Replace the battery cover, making sure it locks in place.

Fig. A



REMOVE FILM FROM TIMER DISPLAY

TO USE COUNT DOWN TIMER (UP TO 99 MIN 59 SEC)

1. Press M (minutes) and S (seconds) buttons for desired timing period. Press and hold the buttons for faster setting.
2. Press START/STOP button to begin timing. The “M” and “S” on the display will flash when the timer is in use.
3. To stop timing, press START/STOP button. To restart the timer, press START/STOP again.
4. After time elapses, alarm beeps for 30 seconds. To stop the beeping, press either the MIN, SEC, or START/STOP button.
5. To reset the timer to 00:00, press the M and S buttons simultaneously.

TO USE TIMER MEMORY RECALL

1. After alarm stops sounding, the pre-set time will appear in the display. Press the START/STOP button to count down again using the same pre-set time.

NOTE: If you stop the timer while it is beeping and you want to recall the pre-set time, simply press the START/STOP button and it will appear on the display. Press the START/STOP button a second time to count down again using the same pre-set time.

TO USE COUNT UP/STOPWATCH

1. Press the M and S buttons simultaneously to reset to 00:00.
2. Press the START/STOP button to start counting up in seconds. The “M” and “S” on the display will flash when the count up/stopwatch is in use.
3. To interrupt the count, press the START/STOP button. To resume counting, press the START/STOP button again.
4. Press the M and S buttons simultaneously to reset to 00:00.

CONSUMER SERVICE INFORMATION

If you have any questions regarding the operation of your PRESTO® appliance, contact us by any of these methods:

- Call 1-800-877-0441 weekdays 8:00 AM to 4:00 PM (Central Time)
- Email us through our website at www.GoPresto.com/contact
- Write: National Presto Ind., Inc., Consumer Service Dept., 3925 N. Hastings Way, Eau Claire, WI 54703-3703

Inquiries will be answered promptly by telephone, email, or letter. When emailing or writing, please include a phone number and a time when you can be reached during weekdays if possible.

Canton Sales and Storage Co., Presto Factory Service Dept., 555 Matthews Dr., Canton, MS 39046-3251

PRESTO® LIMITED WARRANTY

(Applies Only in the United States and Canada)

This quality PRESTO® appliance is designed and built to provide many years of satisfactory performance under normal household use. Presto pledges to the original owner that should there be any defects in material or workmanship during the first year after purchase, we will repair or replace it at our option. Our pledge does not apply to batteries, if any, or to damage caused by shipping. **Outside the United States and Canada, this limited warranty does not apply.**

To obtain service under the warranty, please call our Consumer Service Department at 1-800-877-0441. If unable to resolve the problem, you will be instructed to send your PRESTO® appliance to the Presto Factory Service Department for a quality inspection; shipping costs will be your responsibility. When returning an appliance, please include your name, address, phone number, and the date you purchased the appliance as well as a description of the problem you are encountering with the appliance.

We want you to obtain maximum enjoyment from using this PRESTO® appliance and ask that you read and follow the instructions enclosed. Failure to follow instructions, damage caused by improper replacement parts, abuse, misuse, or neglect will void this pledge. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This is Presto's personal pledge to you and is being made in place of all other express warranties.

NATIONAL PRESTO INDUSTRIES, INC., EAU CLAIRE, WI 54703-3703