

PRESTO®

MyJo™ *single cup coffee maker*

- The convenience of a single serve coffee maker without the high cost.
- Compact design allows you to take it anywhere—home, work, school, travel, or camping.
- Uses convenient single serve packs.

Estas instrucciones también están disponibles en español. Para obtener una copia impresa:

- Descargue en formato PDF en www.GoPresto.com/espanol.
- Envíe un correo electrónico a contact@GoPresto.com.
- Llame al 1-800-877-0441, oprima 2 y deje un mensaje.



Visit us on the web at www.GoPresto.com

INSTRUCTIONS

©2016 National Presto Industries, Inc.

The following important safeguards are recommended by most portable appliance manufacturers.

IMPORTANT SAFEGUARDS

To reduce the risk of personal injury or property damage, when using this appliance, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. Extreme caution must be used when handling a coffee maker containing hot liquid. Do not touch hot surfaces. Grasp the red reservoir grip when handling the reservoir containing hot water.
3. To prevent the risk of injury, avoid contacting the needle in the pack holder.
4. Close supervision is necessary when any appliance is used by or near children.
5. Do not use in the event the coffee maker malfunctions or has been damaged in any manner.
6. The use of accessory attachments not recommended by the appliance manufacturer may damage the unit or cause injuries.
7. Use only water in your MyJo™ coffee maker. Do not fill with any other liquid.
8. Do not fill above the 10-ounce fill line.
9. Do not place on or near a hot gas or electric burner or in a heated oven.
10. Do not use appliance for other than intended use.

SAVE THESE INSTRUCTIONS

Before First Use

1. Become familiar with the MyJo™ coffee maker parts (Fig. A, page 2) and read the following information.
2. Unscrew the base from the reservoir. Then pull out the pump from the reservoir and remove all contents from inside the reservoir.
3. Wash the coffee maker parts in warm, soapy water. Rinse thoroughly to remove any soap residue. **Do not wash the MyJo™ coffee maker in the dishwasher. CAUTION!** There is a sharp needle in the pack holder which is designed to puncture the single serve pack. To prevent injury, do not place fingers in the pack holder.

How To Use

To Prepare Coffee or Tea

The amount of water used with your MyJo™ coffee maker will determine the strength of your coffee or tea. For the first use, fill the water reservoir to the fill lines suggested below:

- For normal strength coffee or tea, fill to the 8-ounce line with water.
- For stronger coffee or tea, fill to the 6-ounce line with water.
- For weaker coffee or tea, fill to the 10-ounce line with water.

For subsequent uses, adjust the strength, if necessary, by simply increasing or decreasing the amount of water as desired. **Note:** The fill line markings provide the necessary water to produce 6, 8, and 10 ounces of brewed coffee or tea.

1. **Place a single serve pack into the pack holder (Fig. B).** Press down firmly on the single serve pack until the bottom of the pack is punctured. **CAUTION!** There is a sharp needle in the pack holder. To prevent injury, do not place fingers in the pack holder.

2. Heat the water and assemble the unit using one of the following methods:

A. Microwave:

- Fill the water reservoir with the desired amount of water.
- Place the filled reservoir in the microwave. **Be sure the base is not attached to the reservoir, as the base is not microwave safe.** Heat water to the desired temperature. **CAUTION!** When handling the reservoir containing hot water, always grasp the red grip as the other portions of the reservoir will be very hot.
- Push the pump cap onto the top of the pump.
- Attach the pump to the reservoir. Insert the ridged portion of the pump into the reservoir, pressing around the pump edge until the pump is attached firmly to the reservoir. **Important:** Press only the pump edge. Do **not** press the pump cap or pump.
- Grasp the red grip on the filled reservoir and place the reservoir onto the base. Screw on clockwise until tight.

B. Tea Kettle:



- Use an electric or stovetop tea kettle and heat water to the desired temperature.
- Attach the base to the reservoir prior to filling it with water. Screw the reservoir on clockwise until tight. Then, place the unit on a dry, level surface and carefully fill the reservoir with the desired amount of heated water. **CAUTION!** Do not hold onto the reservoir when pouring hot water into it.
- Push the pump cap onto the top of the pump.
- Attach the pump to the reservoir. Insert the ridged portion of the pump into the reservoir, pressing around the pump edge until the pump is attached firmly to the reservoir. **Important:** Press only the pump edge. Do **not** press the pump cap or pump.

3. Brew

- The MyJo™ coffee maker is designed to fit on most coffee mugs. Verify that your mug is the right size before pumping your coffee. The ribs on the bottom of the base should fit within the inside rim of your mug; the diameter of the inner rim of the mug should be at least 2¼" but not more than 3¾" wide. You should also make sure you select a mug which is the appropriate size for the amount of coffee or tea you are brewing.
- Place the assembled coffee maker over the selected coffee mug.
- Position the coffee maker and mug directly in front of you. Grasp the coffee maker base with one hand and place the palm of your other hand on the pump cap (Fig. C). If using a tall travel mug, grasp the top portion of the mug instead of the coffee maker base. **Note:** Another method for pumping the water is by placing one hand over the other (Fig. D). However, do not use this method when using tall mugs, such as travel mugs.
- Using the palm of your hand, gradually press down on the pump cap, keeping your hand down until the coffee or tea ceases to flow. Release and allow the pump to return to the original position and press down again. Repeat this process until all the water is expelled through the single serve pack and into your coffee mug. You will hear a swoosh when all of the water has been expelled.
- Lift the coffee maker off the coffee mug and place the coffee maker on a plate or in the sink to catch any residual drops.
- Enjoy your fresh brewed coffee or tea!


To Prepare Hot Cocoa and Other Beverages

When using your MyJo™ coffee maker to prepare other beverages, such as hot cocoa, cappuccino, or hot cider, BEFORE inserting the single serve pack into the holder, place the base over your mug. This will allow any powder residue to be contained in your mug once the pack is punctured since these types of single serve beverages do not have a filter. For the first use, fill the water reservoir to the 6-ounce line. For subsequent uses, adjust the amount of water as desired.



Care and Cleaning

1. Unscrew the base from the reservoir. Turn the base over and use your finger to push the bottom of the used single serve pack out of the holder. Discard the pack. **CAUTION!** There is a sharp needle in the pack holder. To prevent injury, do not place fingers in the pack holder.
2. Pull the pump off of the reservoir and wash the pump, reservoir, and base in warm, soapy water. Rinse and dry. **Do not wash the MyJo™ coffee maker in the dishwasher.**
3. There is a silicone valve located in the inside bottom of the reservoir. If you notice the valve contains coffee grounds or residue, you should remove it for cleaning.



The easiest way to do this is by gently poking the valve at an angle from underneath the reservoir with a blunt object (Fig. E), such as a Q-tip* cotton swab or the eraser end of a pencil. **Note:** There is a slit in the center of the valve so push gently on the outer edge of the valve.

Wash the valve in warm, soapy water. Rinse and reposition the valve in the inside bottom of the reservoir. Use the tip of your index finger or fingernail to press the outer edge tightly in the groove on the floor of the reservoir.

Questions and Answers (Troubleshooting)

Water is seeping out between the base and reservoir. What is happening?

You probably do not have the base screwed on tightly to the water reservoir. Tighten and refill the reservoir with water.

I notice water is leaking out of the reservoir when it's not attached to the base. Why?

There are a couple of things that may be causing this:

- There is a silicone valve located in the inside bottom of the reservoir. The valve may not be seated properly. Use the tip of your index finger or your fingernail to press around the edge of the valve so it fits snugly into the groove on the floor of the reservoir.
- The valve may be dirty. Remove the valve from the reservoir and clean it as instructed in step 3 of the “Care and Cleaning” section.

When I press down on the pump nothing seems to be happening. What am I doing wrong?

- On occasion, the slit in the silicone valve may reseal after manufacturing. This prevents water from being expelled through the unit. Remove the silicone valve from the inside bottom of the reservoir (Fig. E). Pinch the valve and rotate it between your fingers until the slit opens. Reposition the valve in the reservoir and proceed to make your coffee.
- You may not have the pump fully attached to the reservoir and air is escaping. Be sure to press all the way around the pump edge so the ridged portion (see Fig. A, page 2) is fully engaged inside the reservoir rim.
- You may not be applying enough pressure as you are pumping. Stand so you are directly over the coffee maker and press on the pump. Hold the pump down until the coffee ceases to flow, release and allow the pump to return to its original position, and repeat process.

Can I use any brand single serve pack in the MyJo™ coffee maker?

Yes. Any pack that works in the Keurig* K-Cup* system brewer (including packs that have mesh bottoms) will work in the MyJo™ coffee maker. Vue* and Rivo* packs do not work in Keurig* K-Cup* brewers and will not work in the MyJo™ either.

Different brand packs vary in construction. Some have very thin plastic walls that become deformed if boiling water is used. Others have very thin interior filters, which work well with a gentle pumping pressure, but may break when subjected to heavy pressure. Still others have very rigid tops of varying thickness, making them difficult to pierce.

If you experience unusual difficulty pumping and the water in the vessel has turned brown, you have a pack with a thin filter that has broken under pressure. Discard the liquid, clean the unit, and start again, this time applying a gentle steady pressure.

If the water is clear, verify that the top and bottom of the pack are pierced. Carefully unscrew the reservoir from the base. For packs with plastic bottoms, push down to ensure the bottom is pierced. Check the top. If you do not see a small hole in the middle, make one with a knife. Reassemble and resume pumping.

Sometimes, I prefer to use my own coffee grounds rather than a single serve pack. Is there a refillable filter cup that I can use with the MyJo™ coffee maker?

Yes. There is one cup that is designed to work in the MyJo™ coffee maker, the MyJo™ Cup. To order, see page 4. Do not use any other brand of cup.

* “Q-tip” is a registered trademark of Conopco, Inc. “K-Cup”, “Keurig”, and “Vue” are registered trademarks of Keurig, Green Mountain Inc. “Rivo” is a registered trademark of Green Mountain Coffee Roasters, Inc. Presto is not affiliated with these companies.

Consumer Service Information

If you have any questions regarding the operation of your PRESTO® appliance or need parts for your appliance, contact us by any of these methods:

- Call 1-800-877-0441 weekdays 8:00 AM to 4:00 PM (Central Time)
- Email us through our website at www.GoPresto.com/contact
- Write: National Presto Industries, Inc., Consumer Service Dept.
3925 North Hastings Way, Eau Claire, WI 54703-3703

Inquiries will be answered promptly by telephone, email, or letter. When emailing or writing, please include a phone number and a time when you can be reached during weekdays if possible. When contacting the Consumer Service Department, please indicate the model and series numbers for the coffee maker. These numbers can be found on the bottom of the coffee maker base. Please record this information:

Model _____ Series _____ Date Purchased _____

The Presto Factory Service Department is equipped to service PRESTO® appliances and supply genuine PRESTO™ replacement parts. Genuine PRESTO™ replacement parts are manufactured to the same exacting quality standards as PRESTO® appliances and are engineered specifically to function properly with its appliances. Presto can only guarantee the quality and performance of genuine PRESTO™ replacement parts. “Look-alikes” might not be of the same quality or function in the same manner. To ensure that you are buying genuine PRESTO™ replacement parts, look for the PRESTO trademark.

Canton Sales and Storage Co., Presto Factory Service Dept.
555 Matthews Drive, Canton, MS 39046-3251

Perfect companions for your Presto® MyJo™ coffee maker

Presto® Electric Tea Kettle (Part 02703)

This tea kettle is ideal for heating water to use in the MyJo™ coffee maker. It can go almost anywhere you go... home, work, even the cabin. Boil up to a full quart of water faster than a microwave. The built-in whistle indicates when water is boiling, and the thermostat automatically shuts the tea kettle off if it boils dry. The flip-up stainless steel lid makes filling easy and directs steam away when pouring. Anodized interior base resists mineral buildup.



Presto® MyJo™ Cup (Part 44364)

Use this cup with your MyJo™ coffee maker to make coffee or tea from your favorite ground coffee or tea leaves.



How to Order

Call toll-free 1-800-995-9960 weekdays between 8:00 AM and 4:00 PM Central Time. Please have your credit card number and expiration date ready. Payment options limited to credit card only. These products are available to addresses in the United States, Puerto Rico, and the US Virgin Islands only.

PRESTO® Limited Warranty

(Applies Only in the United States and Canada)

This quality PRESTO® appliance is designed and built to provide many years of satisfactory performance under normal household use. Presto pledges to the original owner that should there be any defects in material or workmanship during the first year after purchase, we will repair or replace it at our option. Our pledge does not apply to damage caused by shipping. **Outside the United States and Canada, this limited warranty does not apply.**

To obtain service under the warranty, please call our Consumer Service Department at 1-800-877-0441. If unable to resolve the problem, you will be instructed to send your PRESTO® appliance to the Presto Factory Service Department for a quality inspection; shipping costs will be your responsibility. When returning an appliance, please include your name, address, phone number, and the date you purchased the appliance as well as a description of the problem you are encountering with the appliance.

We want you to obtain maximum enjoyment from using this PRESTO® appliance and ask that you read and follow the instructions enclosed. Failure to follow instructions, damage caused by improper replacement parts, abuse, misuse, alterations, or neglect will void this pledge. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This is Presto's personal pledge to you and is being made in place of all other express warranties.

NATIONAL PRESTO INDUSTRIES, INC.
EAU CLAIRE, WI 54703-3703